



Experience is the solution

PCB sampling, laboratory analysis,  
EPA method 1631: SUNY New Paltz

## **POLYCHLORINATED BIPHENYL (PCB) SAMPLING**

*September 1997*

Prepared for:

**SUNY New Paltz  
75 South Manheim Blvd., Suite 9  
New Paltz, New York 12561**

Prepared by:

**Adirondack Environmental Services, Inc.  
260 Broadway, Suite 201  
Saratoga Springs, NY 12866**

Adirondack Project No. 970815EA

## **TABLE OF CONTENTS**

<b>EXECUTIVE SUMMARY</b>	<b>E-1</b>
<b>1.0 INTRODUCTION</b>	<b>0-1</b>
<b>2.0 SAMPLING STRATEGY AND METHODOLOGY</b>	<b>1-1</b>
<b>2.1 SAMPLING STRATEGY</b>	<b>1-1</b>
<b>2.2 SAMPLING AND ANALYTICAL METHODOLOGY</b>	<b>1-1</b>
2.2.1 Wipe Sampling	1-1
2.2.2 Air Sampling	1-2
<b>3.0 RESULTS AND OBSERVATIONS</b>	<b>2-1</b>
<b>3.1 RESULTS</b>	<b>2-1</b>
3.1.1 PCB Wipe Sampling	2-1
3.1.2 PCB Air Sampling	2-1
<b>3.2 OBSERVATIONS</b>	<b>2-1</b>
<b>4.0 DISCUSSION AND CONCLUSION</b>	<b>3-1</b>

## **APPENDICES**

<b>APPENDIX A</b>	<b>SUNY NEW PALTZ AIR AND WIPE SAMPLING STRATEGY</b>
<b>APPENDIX B</b>	<b>WIPE AND AIR SAMPLE LOCATIONS</b>
<b>APPENDIX C</b>	<b>WIPE SAMPLING LABORATORY REPORT AND CHAIN OF CUSTODY DOCUMENTATION</b>
<b>APPENDIX D</b>	<b>AIR SAMPLING LABORATORY REPORT AND CHAIN OF CUSTODY DOCUMENTATION</b>
<b>APPENDIX E</b>	<b>WIPE SAMPLING FIELD DATA SHEETS</b>
<b>APPENDIX F</b>	<b>AIR SAMPLING FIELD DATA SHEETS</b>

## *EXECUTIVE SUMMARY*

On August 18 and 19, 1997, Adirondack Environmental Services, Inc. (Adirondack) performed Polychlorinated Biphenyl (PCB) area air and wipe sampling in the Residence Halls located on the State University of New York (SUNY) New Paltz Campus. All monitoring and analysis activities were performed in accordance with the SUNY New Paltz Polychlorinated Biphenyl Air and Wipe Sampling Strategy, dated August 1997. The purpose of the sampling was to ensure that the four residence halls located on the campus were free of PCB contamination within a statistical confidence limit of 95%.

A total of 29 wipe samples and three field blanks and 30 air samples and three blanks were collected in randomly selected rooms in the four residence halls. Both the wipe sample locations and the area air sample locations were selected with a random number table. Samples were collected, labeled and placed on ice and delivered to the laboratory. Wipe samples were analyzed by the EPA 8080 method and the air samples were analyzed by the New York State Department of Health (NYDOH) method DOH 311-1.

The analysis of the 32 wipe samples collected indicated all results to be less than the detection limit of the analysis  $<0.1 \text{ ug}/100\text{cm}^2$  ( $<1 \text{ ug}$  per  $900 \text{ cm}^2$ ). The analysis of the 33 air samples collected indicated results to be less than the detectable limits of the analysis ( $<0.2 \text{ ug}/\text{m}^3$ ) for all of the samples except one. Field sample identification number A24 (laboratory identification number 970820EA12) indicated a concentration of  $0.3 \text{ ug}/\text{m}^3$  for Aroclor 1242 and  $0.2 \text{ ug}/\text{m}^3$  for Aroclor 1254. This sample was obtained outside Gage Hall.

The results of the wipe and air sampling indicate that all sample results were below Environmental Protection Agency, Occupational Safety and Health Administration and National Institute for Occupational Safety and Health published exposure limits for PCBs.

*INTRODUCTION*

On August 18 and 19, 1997, Mr. Paul Watson, CIH, CET and Mr. John Frisone, Industrial Hygiene Technician of Adirondack Environmental Services, Inc. (Adirondack) performed Polychlorinated Biphenyl (PCB) area air and wipe sampling in the four residence halls located on the State University of New York (SUNY), New Paltz Campus. The sampling team was escorted by Mr. Peter Betley of the SUNY New Paltz, Health and Safety Department. All monitoring and analysis activities were performed in accordance with the SUNY New Paltz Polychlorinated Biphenyl Air and Wipe Sampling Strategy, dated August 1997. A copy of the sampling strategy is located in Appendix A. The purpose of the sampling was to ensure that the four residence halls were free of PCB contamination that may have resulted from a release that occurred on December 29, 1991. The PCB material may have entered the residence halls by way of open windows, doors, and the ventilation systems. These residence halls were subsequently cleaned after the release and this sampling was conducted to ensure that the residence halls did not contain any residual material at a statistical confidence limit of 95%.

The sampling strategy and methodology used to complete the sampling is described in Section 2. The sample results and observations are presented in Section 3 and discussed in Section 4. The SUNY New Paltz Air and Wipe Sampling Strategy is included in Appendix A and the exact wipe and air sample locations are identified in Appendix B. The remaining Appendices present the laboratory results and field sampling data sheets.

## 2.0 *SAMPLING STRATEGY AND METHODOLOGY*

### 2.1 *SAMPLING STRATEGY*

The purpose of the exposure assessment was to obtain statistically representative wipe and air samples of the various residence hall rooms. A sampling strategy was designed to meet this objective. The sampling strategy developed for the facility is presented in Appendix A. This strategy served as a guide for the quantitative monitoring performed in this assessment.

### 2.2 *SAMPLING AND ANALYTICAL METHODOLOGY*

#### 2.2.1 *Wipe Sampling*

Wipe samples were obtained utilizing 900 cm<sup>2</sup>, disposable cardboard templates. Sample technicians utilized latex gloves and laboratory prepared swabs. Wipe sampling was performed by wiping a laboratory prepared filter paper over a 900 square centimeter area. The filter paper was prepared with 10 milliliters (ml) of reagent grade hexane. The pretreated wipes were replaced in the glass vials for storage and transport to the laboratory. All of the samples collected were assigned a sequential sample identifier and sample locations were plotted on site plans supplied by SUNY New Paltz. Wipe sample locations were selected with a random number table. Floor or desk top locations were selected in a similar fashion. All floor samples were obtained in the center of the residence hall rooms, except where otherwise noted on the field sample data sheets. All desk top samples were obtained in the area defined as the student's work area (that area directly in front of where a student may sit at the desk). All wipe samples were documented on a sampling record. This record included the location (identified by name and at least two measurements with a tape measure), date, room number, building and samplers name. All samples were assigned a unique sequential sample number. All samples were labeled, placed on ice and driven to the laboratory for analysis. Samples were analyzed by the EPA 8080 method for the following Aroclors; 1016, 1221, 1232, 1242, 1248, 1254 and 1260.

Identification of any PCB concentrations above 500 micrograms was to be confirmed by gas chromatography/mass spectrometry (GC/MS), however no peaks were identified above this level. The selection of this method was consistent with the methods previously utilized at SUNY New Paltz.

### 2.2.2

#### *Air Sampling*

Thirty-three air samples were collected using Mine Safety Appliances (MSA) Flow-lite air sampling pumps. All air sampling pumps were calibrated before and after sampling with a BIOS Dry Cal primary standard. All air samples were obtained in the center of the residence hall rooms with the doors and windows closed. All air samples were documented on an air sampling record. This record included the exact run time, pre and post calibration information, sample location and sampler's name. All samples were assigned a unique sequential identification number. Three (3) field blanks were submitted as per the sampling strategy. Blanks were not identified to the analytical laboratory and were assigned a sequential sample number.

Samples were analyzed by the DOH 311-1 method Analysis targeted the following Aroclors; 1016, 1221, 1232, 1242, 1248, 1254, and 1260. This method was selected to be consistent with previous air monitoring performed at SUNY New Paltz.

All air and wipe samples were submitted under chain of custody documentation to Adirondack's laboratory in Albany, New York for analysis. Wipe and air samples were stored in separate ice chests for delivery to the laboratory. Adirondack is accredited by the American Industrial Hygiene Association (AIHA), accreditation number 490.

### 3.0 **RESULTS AND OBSERVATIONS**

#### 3.1 **RESULTS**

##### 3.1.1 *PCB Wipe Sampling*

The analysis of the 32 wipe samples collected indicated all results to be less than the detection limit of the analysis,  $<0.1 \text{ ug}/100\text{cm}^2$  ( $<1 \text{ ug}$  per  $900 \text{ cm}^2$ ). These results can be compared to the Environmental Protection Agency's clean up criteria for a high contact residential/commercial areas of  $10 \text{ ug}/100 \text{ cm}^2$ . Wipe sample locations are presented in Appendix B, Table 1.

##### 3.1.2 *PCB Air Sampling*

The analysis of the 33 air samples collected indicated results to be less than the detectable limits of the analysis ( $<0.2 \text{ ug}/\text{m}^3$ ) for all of the samples except one. Field sample identification number A24 (laboratory identification number 970820EA12) indicated a concentration of  $0.3 \text{ ug}/\text{m}^3$  for Aroclor 1242 and  $0.2 \text{ ug}/\text{m}^3$  for Aroclor 1254. This sample was obtained outside Gage Hall. These results can be compared to the Occupational Safety and Health Administration's (OSHA) Permissible Exposure Limit (PEL) of  $500 \text{ ug}/\text{m}^3$  for Aroclor 1254 and  $1000 \text{ ug}/\text{m}^3$  for Aroclor 1242. These are the only two Aroclors that OSHA has established PELs. The National Institute for Occupational Safety and Health (NIOSH) Recommended Exposure Limit (REL) for all PCBs is  $1 \text{ ug}/\text{m}^3$ . Air sample locations are listed in Appendix B, Table 2.

#### 3.2 **OBSERVATIONS**

Wipe sampling was conducted in unoccupied residence hall rooms. Where possible, SUNY New Paltz identification tags were utilized to identify desk tops that were sampled. However the identification tags were not always readily visible on the furniture and therefore were not documented.

All air monitoring was conducted with the doors and windows closed. All rooms

were unoccupied except for the following; Bliss Hall rooms 114, 223; Gage Hall 203, 325; Scudder Hall B3; and Capen Hall room 121. Students were not present in the rooms during the air monitoring periods.

Sample number A31 (room 214, Bliss Hall) was voided due to an air sampling pump failure. A31 was replaced with sample identifier A31A and was resampled.



**DISCUSSION AND CONCLUSION**

Based upon the findings, all sample results were less than the detection limits of the analysis except for one air sample, field number A24. This sample was obtained outside Gage Hall. This sample indicated two Aroclors (1242 and 1254) at the detection limit of the analysis.

It may be likely that the two Aroclors were components in the transformer oil (this oil was identified as Aroclor 1260) from the release incident. Commercial PCBs were generally mixtures of many different chlorinated biphenyls that were manufactured to meet specific requirements. These mixtures varied from batch to batch. Another possible explanation of the results is that the source of the material was from an off site release. PCBs can be present as solid or liquid aerosols and as vapors and depending on the type of PCB they can remain airborne for up to ten days. While dispensed in the air PCBs can travel fairly long distances.

The New York State Department of Health is currently conducting quarterly air monitoring on campus. These results should be compared to previously obtained results to determine if these Aroclors have been identified and are, as suspected, transient in nature.

Adirondack recommends that SUNY New Paltz maintain this and all previous sampling results for future reference.

**APPENDIX A**  
**SUNY NEW PALTZ AIR AND WIPE SAMPLING**  
**STRATEGY**



**Experience is the solution**

# **POLYCHLORINATED BIPHENYL AIR AND WIPE SAMPLING STRATEGY**

*August 1997*

**Prepared for:**

**State University of New York, New Paltz Campus  
Mr. Peter Betley  
75 South Manheim Blvd., Suite 9  
New Paltz, New York 12561**

**Prepared by:**

**Adirondack Environmental Services, Inc.  
260 Broadway, Suite 201  
Saratoga Springs, NY 12866**

**Adirondack Project No. 970805EB**

## **TABLE OF CONTENTS**

<b>1.0</b>	<b>INTRODUCTION</b>	<b>1-1</b>
<b>2.0</b>	<b>SAMPLING STRATEGY AND METHODOLOGY</b>	<b>2-1</b>
<b>2.1</b>	<b>SAMPLING STRATEGY</b>	<b>2-3</b>
<b>2.2</b>	<b>SAMPLING AND ANALYTICAL METHODOLOGY</b>	<b>2-3</b>
<b>2.3</b>	<b>SAMPLING HANDLING</b>	<b>2-5</b>
<b>2.4</b>	<b>PRESENTATION OF RESULTS</b>	<b>2-6</b>
<b>3.0</b>	<b>REFERENCES</b>	<b>3-1</b>

## **APPENDICES**

<b>APPENDIX A</b>	<b>RESIDENCE HALL ROOM LISTING</b>
<b>APPENDIX B</b>	<b>EPA METHOD 8080</b>
<b>APPENDIX C</b>	<b>NEW YORK STATE DEPARTMENT OF HEALTH METHOD 311-1</b>
<b>APPENDIX D</b>	<b>PCB WIPE SAMPLE LOCATIONS</b>
<b>APPENDIX E</b>	<b>PCB AIR SAMPLE LOCATIONS</b>

*INTRODUCTION*

The following sampling plan has been developed to ensure that the four residence halls located on the State University of New York (SUNY) New Paltz campus are free of potential Polychlorinated Biphenyl (PCB) contamination. Area air monitoring and wipe sampling on horizontal surfaces have been prescribed. The number of air and wipe samples have been selected to provide a statistical confidence limit of 95%. Sampling methodology, selection of sample locations, and analytical methods are described in the text below.

## *SAMPLING STRATEGY AND METHODOLOGY*

The purpose of the air and wipe sampling plan is to devise a statistically significant approach to the evaluation of approximately 422 residence hall rooms for PCB contamination.

In order to develop this sampling plan a few assumptions have been made. The first is that the four residence halls (approximately 422 rooms total, a room listing appears in Appendix A) have the same risk of potential exposure and are therefore defined as one homogeneous risk group. This assumption was based upon the information provided from SUNY New Paltz that the PCB release that occurred on December 29, 1991, may have emitted airborne PCBs. The PCB material may have entered the residence halls by way of open windows, doors, and the ventilation systems.

The second assumption is that PCB contamination is most likely present in the form of dust contamination and that horizontal surfaces (floors and desk tops) would be the most likely locations to detect any PCB material.

The final assumption that has been made is that the largest population that spends the greatest amount of time in the residence halls is the students. The majority of the students time spent would most likely be in the residence hall rooms, therefore sampling will concentrate on these areas and will exclude hallways, kitchen and common areas. Student contact with any potential PCB material would most likely be on the working area of the desk (approximately center) and the open areas of the floor (approximately center).

In determining that the four residence halls are free of PCB material, it will be necessary to randomly select rooms to be sampled. The sample group must be of sufficient size to ensure that the random sample will have a high probability to contain at least one sample containing PCB contamination if one exists. The number of samples ( represented by  $n$ ) to be collected from the homogenous risk group is dependent on the number of areas in the risk group (represented by  $N$ ),

and the statistical confidence required (in this instance 95% confidence to collect at least one sample in the highest 10% of potential contamination).

Sample size  $n$  can be determined from a complex formula or by using the Table 1, Calculation of Sample Size for a Maximum Risk Subgroup from a Homogenous Exposure Risk Group. Prior to using the table, the following variables must be determined:

$N$  = Size of the population with potential contamination (422 rooms in this case).

$n$  = Size of the sample subgroup to be selected from the homogenous risk group.

$\alpha$  = Allowed probability of missing all of the areas in the top contamination group ( $\alpha=0.05$  for the 95% confidence level).

$\tau$  = Proportion of the group included as the high exposures-desired high in the exposure subgroup percentage ( $\tau=0.1$  for the top 10% of all exposures).

From Table 1, the number of air and wipe samples for a population of 422 rooms, with a 95% confidence and a top 10% desired high exposure subgroup yields 29 samples each.

**Table 1 - Calculation of Sample Size for a Maximum Risk Subgroup From a Homogeneous Exposure Risk Group**

Size of partial Sample for Top 10% ( $\tau=0.1$ ) and Confidence 0.95 ( $\alpha=0.05$ ) (use  $n-N$  if  $N<11$ )

Size of Group, $N$	Number of Required Samples, $n$
12	11
13-14	12
15-16	13
17-18	14
19-21	15
22-24	16
25-27	17
28-31	18
32-35	19
36-41	20
42-50	21
$\infty$	29

## 2.1 *SAMPLING STRATEGY*

### 2.1.1 *Wipe Samples*

Wipe sample locations (29) have been selected by assigning sequential numbers to each residence hall room starting with the number one (approximately 422 rooms, a room listing appears in Appendix A). Identified wipe sample locations appear in Appendix D. Locations must be indicated on drawings supplied by SUNY New Paltz. A random number table generator was utilized to select twenty-nine wipe sample locations. Once the rooms have been identified, the random number generator was utilized to determine whether a floor or desk top surface will be wiped. This was accomplished by assigning a unique number to the desk top location and one to the floor location. The random number table was then used to select the sample location. The sample location (the floor or desk top) must be documented on the SUNY New Paltz supplied site plan.

Samples will be obtained from the approximate center of the desk top or floor surface.

### 2.1.2 *Air Samples*

Area air sample locations were determined by assigning sequential number to each residence hall room starting with the number one (approximately 422 rooms, a room listing appears in Appendix A). Sample locations and sample numbers must be identified on drawings supplied by SUNY New Paltz. A random number table was utilized to select twenty-nine sample locations for the area air samples. Samples will be obtained at approximately four to five feet above the floor in order to represent a person's breathing zone. Samples will be taken in the center of the room with the doors and windows closed. One ambient outside air sample will also be obtained for comparison purposes.

## 2.2 *SAMPLING AND ANALYTICAL METHODOLOGY*



### 2.2.1

#### *Wipe Samples*

Wipe sampling will be performed by wiping a laboratory prepared four inch square gauze or glass wool wipe over a 900 square centimeter area. The filter paper will be prepared with 10 milliliters of reagent grade hexane. The pretreated wipes will be placed in a glass vial for storage and use. A pre cut 900 square centimeter reusable stainless steel templates will be utilized. This template will be supplied by SUNY New Paltz. The template will be decontaminated in-between each sample by wiping the entire surface with hexane and disposable towels. Disposable cardboard templates of the same size may also be used. These templates must be discarded after each sample. The sample technician will wear disposable gloves during the collection and handling of each sample to prevent potential sample cross contamination and skin exposure. All wipe samples will be documented on a sampling record. This record shall include at a minimum the location (to be identified by name and at least two measurements with a tape measure), date, room number, building and samplers name. All samples will be assigned a unique sequential sample number. Ten percent field blanks (3) will be submitted at the time of analysis. Blanks must not be identified to the analytical laboratory and must be assigned a sequential sample number. Blanks will be unopened laboratory prepared filters. Wipe samples will be obtained on horizontal surfaces only (floors and desk tops).

The analytical method will be EPA Method 8080 utilizing gas chromatography with an electron capture detector (GC/ECD). Identified PCB concentrations above 500 micrograms will be confirmed by gas chromatography/mass spectrometry (GC/MS). The following Aroclors must be targeted and quantified; 1016, 1221, 1232, 1242, 1248, 1254, and 1260. A copy of the method is included in Appendix B. The selection of this method is consistent with the methods previously utilized at SUNY New Paltz.

### 2.2.2

#### *Air Samples*

The New York State Department of Health Method 311-1, Polychlorinated

Biphenyls in Ambient Air, will be utilized as the air sampling and analytical method. Samples will be obtained with an air sampling pump, flexible tubing and appropriate media as outlined in the method. Sample time will be from four to eight hours at one liter per minute. A copy of the method is included in Appendix C. All samples will be pre and post calibrated with a National Institute of Standards and Technology (NIST) traceable primary standard such as a Gillian Gilibrator, Bios DRY CAL or equivalent. All air samples will be documented on an air sampling record. This record shall include at a minimum the run time, pre and post calibration information, sample location and samplers name. All samples will be assigned a unique sequential sample number. Ten percent field blanks (3) will be submitted at the time of analysis. Blanks must not be identified to the analytical laboratory and must be assigned a sequential sample number. Analysis must identify and quantify the following Aroclors; 1016, 1221, 1232, 1242, 1248, 1254, and 1260. This method was selected to be consistent with previous air monitoring performed at SUNY New Paltz.

## 2.3 **SAMPLING HANDLING**

### 2.3.1 *Wipe samples*

Immediately after wipe sampling, return the sample to the glass vial. Label the vial with an unique sample number and secure the sample for transport. Samples will be shipped to the laboratory in an ice chest in order to maintain the samples at 4<sup>o</sup> Celsius.

All samples must be accompanied to the laboratory with a properly completed chain of custody record.

All wipe samples must be shipped to the laboratory in a separate container from any air samples.

### 2.3.2 *Air Samples*

The air sampling train will be disassembled after completion of sampling. The

florisil tube will be capped immediately and labeled with a unique sample number and will be placed in a clean zip lock bag. The bag will be labeled with the unique sample number and secured for transport to the laboratory.

All samples must be accompanied to the laboratory with a properly completed chain of custody record. Samples will be shipped to the laboratory in an ice chest in order to maintain the samples at 4<sup>0</sup> Celsius

All air samples must be shipped to the laboratory in a separate container from any wipe samples.

#### 2.4

#### *PRESENTATION OF RESULTS*

All supporting sampling documentation including chain of custody records, air sampling data forms, wipe sampling forms, and laboratory analytical results will be presented in a written report. The format will be determined by SUNY New Paltz. Wipe sample results will be compared to the Environmental Protection Agency's clean up criteria for a high contact residential/commercial area of 10 micrograms/100 square centimeters. Air sample results will be compared to the outside sample, sample blanks, and to National Institute for Occupational Safety and Health Administration airborne limits.

**REFERENCES**

Environmental Protection Agency, 40 CFR Part 761, Polychlorinated Biphenyls Spill Cleanup Policy: Final Rule

Environmental Protection Agency, Field Manual For Grid Sampling of PCB Spill Sites to Verify Cleanup, EPA Document Number 560/5-86-017

Environmental Protection Agency, Verification of PCB Spill Cleanup By Sampling and Analysis, EPA Document Number 560/5-86-026

National Institute for Occupational Safety and Health, Occupational Sampling Strategy Manual, DHEW Document Number 77-173

# SCUDDER HALL, BUILDING #20

<u>Basement</u>	120	311
B1	122	313
B2	124	315
B3		316
B4	<u>Second Floor</u>	317
B5	203	319
B6	205	321
B7	207	323
B8	208	324
B9	209	325
B10	211	327
B11	213	329
B12	215	301
B13	216	303
B14	217	305
B15	219	307
B16	221	310
B17 Overflow	223	312
	224	314
<u>First Floor</u>	225	318
103	227	320
105	229	322
107	201	326
108	202	328
109	204	330
Director's Apartment	206	331
113	210	
115	212	
116	214	
117	218	
119	220	
121	222	
123	226	
101	228	
102	230	
104	231	
106		
110	<u>Third Floor</u>	
111	302	
Guest Room	304	
112	306	
114	308	
118	309	

# Capen Hall, Building #9

<u>Basement</u>	211	327
B4	213	329
B5	215	301
B6	216	303
B7	217	305
B8	219	307
B9	221	310
B10	223	312
B11	224	314
B12	225	318
B13	227	320
B14	229	322
B15	201	326
	202	328
	204	330
<u>First Floor</u>	206	331
103	210	
105	212	
107	214	
108	218	
RD's Apartment	220	
113	222	
115	226	
116	228	
117	230	
119	231	
121		
123		
101HC	<u>Third Floor</u>	
102HC	302	
104HC	304	
110	306	
118HC	308	
120HC	309	
122HC	311	
124HC	313	
	315	
	316	
<u>Second Floor</u>	317	
203	319	
205	321	
207	323	
208	324	
209	325	

# GAGE HALL, BUILDING #21

<u>Basement East</u>	<u>First Floor West</u>	218
B1	115	220
B2	117	221
B3	119	222
B4	121	
B5	127	<u>Second Floor West</u>
B6	129	227
B7	131	229
B8	133 Overflow	231
B9	116	233
B10	118	235
	120	237
<u>Basement West</u>	122	243
B11	123	245
B12	124	247
B13	124 Overflow	249
B14	125	225
B15	126	226
B16	128	228
B17	130	230
B18	132	232
B19		234
B20	<u>Second Floor East</u>	236
B21	202	238
	204	239
<u>First Floor East</u>	206	240
101	208	241
103	209	242
105	210	244
107	211	246
108	212	248
108 Overflow	213	
109	215	<u>Third Floor East</u>
110	217	302
111	219	304
112	223	306
113	224	308
114	201	309
100 Overflow	203	310
102	205	311
104	207	312
106	214	313
RD's Apartment	216	315

317  
319  
323  
324  
301  
303  
305  
307  
314  
316  
318  
320  
321  
322

Third Floor West

327  
329  
331  
333  
335  
337  
343  
345  
347  
349  
325  
326  
328  
330  
332  
334  
336  
338  
339  
340  
341  
342  
344  
346  
348



# BLISS HALL, BUILDING #22

## BASEMENT

B00 Overflow  
 B1 Overflow  
 B2 Overflow  
 B3  
 B4  
 B5  
 B6  
 B7  
 B8  
 B9  
 B10  
 B11  
 B13  
 B14  
 B15  
 B16  
 B17 Overflow

116  
 117  
 119  
 121  
 123

## Second Floor

201  
 202  
 204  
 206  
 210  
 212  
 214  
 218  
 220  
 222  
 226  
 228  
 230  
 231  
 203  
 205  
 207  
 208  
 209  
 211  
 213  
 215  
 216  
 217  
 219  
 221  
 223  
 224  
 225  
 227  
 229

## Third Floor

301  
 303  
 305  
 307  
 310  
 312  
 314  
 318  
 320  
 322  
 326  
 328  
 330  
 331  
 302  
 304  
 306  
 308  
 309  
 311  
 313  
 315  
 316  
 317  
 319  
 321  
 323  
 324  
 325  
 327  
 329

## FIRST FLOOR

101  
 102  
 104  
 106  
 110  
 111  
 Guest Room  
 112 Overflow  
 112  
 114  
 118  
 120  
 122  
 124  
 103  
 105  
 107  
 108  
 109  
 Director's Apartment  
 113  
 115

METHOD 8080A

ORGANOCHLORINE PESTICIDES AND POLYCHLORINATED BIPHENYLS  
BY GAS CHROMATOGRAPHY

1.0 SCOPE AND APPLICATION

1.1 Method 8080 is used to determine the concentration of various organochlorine pesticides and polychlorinated biphenyls (PCBs). The following compounds can be determined by this method:

Compound Name	CAS No. <sup>a</sup>
Aldrin	309-00-2
$\alpha$ -BHC	319-84-6
$\beta$ -BHC	319-85-7
$\delta$ -BHC	319-86-8
$\gamma$ -BHC (Lindane)	58-89-9
Chlordane (technical)	12789-03-6
4,4'-DDD	72-54-8
4,4'-DDE	72-55-9
4,4'-DDT	50-29-3
Dieldrin	60-57-1
Endosulfan I	959-98-8
Endosulfan II	33212-65-9
Endosulfan sulfate	1031-07-8
Endrin	72-20-8
Endrin aldehyde	7421-93-4
Heptachlor	76-44-8
Heptachlor epoxide	1024-57-3
4,4'-Methoxychlor	72-43-5
Toxaphene	8001-35-2
Aroclor-1016	12674-11-2
Aroclor-1221	1104-28-2
Aroclor-1232	11141-16-5
Aroclor-1242	53469-21-9
Aroclor-1248	12672-29-6
Aroclor-1254	11097-69-1
Aroclor-1260	11096-82-5

a Chemical Abstract Services Registry Number.

1.2 Table 1 lists the method detection limit for each compound in organic-free reagent water. Table 2 lists the estimated quantitation limit (EQL) for other matrices.

## 2.0 SUMMARY OF METHOD

2.1 Method 8080 provides gas chromatographic conditions for the detection of ppb concentrations of certain organochlorine pesticides and PCBs. Prior to the use of this method, appropriate sample extraction techniques must be used. Both neat and diluted organic liquids (Method 3580, Waste Dilution) may be analyzed by direct injection. A 2 to 5  $\mu\text{L}$  sample is injected into a gas chromatograph (GC) using the solvent flush technique, and compounds in the GC effluent are detected by an electron capture detector (ECD) or an electrolytic conductivity detector (HECD).

2.2 The sensitivity of Method 8080 usually depends on the concentration of interferences rather than on instrumental limitations. If interferences prevent detection of the analytes, Method 8080 may also be performed on samples that have undergone cleanup. Method 3620, Florisil Column Cleanup, by itself or followed by Method 3660, Sulfur Cleanup, may be used to eliminate interferences in the analysis.

## 3.0 INTERFERENCES

3.1 Refer to Methods 3500, 3600, and 8000.

3.2 Interferences by phthalate esters can pose a major problem in pesticide determinations when using the electron capture detector. These compounds generally appear in the chromatogram as large late-eluting peaks, especially in the 15% and 50% fractions from the Florisil cleanup. Common flexible plastics contain varying amounts of phthalates. These phthalates are easily extracted or leached from such materials during laboratory operations. Cross contamination of clean glassware routinely occurs when plastics are handled during extraction steps, especially when solvent-wetted surfaces are handled. Interferences from phthalates can best be minimized by avoiding contact with any plastic materials. Exhaustive cleanup of reagents and glassware may be required to eliminate background phthalate contamination. The contamination from phthalate esters can be completely eliminated with a microcoulometric or electrolytic conductivity detector.

## 4.0 APPARATUS AND MATERIALS

### 4.1 Gas chromatograph

4.1.1 Gas Chromatograph: Analytical system complete with gas chromatograph suitable for on-column injections and all required accessories, including detectors, column supplies, recorder, gases, and syringes. A data system for measuring peak heights and/or peak areas is recommended.

### 4.1.2 Columns

4.1.2.1 Column 1: Supelcoport (100/120 mesh) coated with 1.5% SP-2250/1.95% SP-2401 packed in a 1.8 m x 4 mm ID glass column or equivalent.

4.1.2.2 Column 2: Supelcoport (100/120 mesh) coated with 3% OV-1 in a 1.8 m x 4 mm ID glass column or equivalent.

4.1.3 Detectors: Electron capture (ECD) or electrolytic conductivity detector (HECD).

4.2 Kuderna-Danish (K-D) apparatus:

4.2.1 Concentrator tube: 10 mL, graduated (Kontes K-570050-1025 or equivalent). A ground-glass stopper is used to prevent evaporation of extracts.

4.2.2 Evaporation flask: 500 mL (Kontes K-570001-500 or equivalent). Attach to concentrator tube with springs, clamps, or equivalent.

4.2.3 Snyder column: Three ball macro (Kontes K-503000-0121 or equivalent).

4.2.4 Snyder column: Two ball micro (Kontes K-569001-0219 or equivalent).

4.2.5 Springs - 1/2 inch (Kontes K-662750 or equivalent).

4.3 Boiling chips: Solvent extracted, approximately 10/40 mesh (silicon carbide or equivalent).

4.4 Water bath: Heated, with concentric ring cover, capable of temperature control ( $\pm 5^{\circ}\text{C}$ ). The bath should be used in a hood.

4.5 Volumetric flasks, Class A: sizes as appropriate with ground-glass stoppers.

4.6 Microsyringe: 10  $\mu\text{L}$ .

4.7 Syringe: 5 mL.

4.8 Vials: Glass, 2, 10, and 20 mL capacity with Teflon-lined screw caps or crimp tops.

4.9 Balances: Analytical, 0.0001 g and Top loading, 0.01 g.

## 5.0 REAGENTS

5.1 Reagent grade chemicals shall be used in all tests. Unless otherwise indicated, it is intended that all reagents shall conform to the specifications of the Committee on Analytical Reagents of the American Chemical Society, where such specifications are available. Other grades may be used, provided it is first ascertained that the reagent is of sufficiently high purity to permit its use without lessening the accuracy of the determination.

5.2 Organic-free reagent water - All references to water in this method refer to organic-free reagent water, as defined in Chapter One.

### 5.3 Solvents

5.3.1 Hexane,  $C_6H_{14}$  - Pesticide quality or equivalent.

5.3.2 Acetone,  $CH_3COCH_3$  - Pesticide quality or equivalent.

5.3.3 Toluene,  $C_6H_5CH_3$  - Pesticide quality or equivalent.

5.3.4 Isooctane,  $(CH_3)_3CCH_2CH(CH_3)_2$  - Pesticide quality or equivalent.

### 5.4 Stock standard solutions:

5.4.1 Prepare stock standard solutions at a concentration of 1000 mg/L by dissolving 0.0100 g of assayed reference material in isooctane and diluting to volume in a 10 mL volumetric flask. A small volume of toluene may be necessary to put some pesticides in solution. Larger volumes can be used at the convenience of the analyst. When compound purity is assayed to be 96% or greater, the weight can be used without correction to calculate the concentration of the stock standard. Commercially prepared stock standards can be used at any concentration if they are certified by the manufacturer or by an independent source.

5.4.2 Transfer the stock standard solutions into vials with Teflon-lined screw caps or crimp tops. Store at 4°C and protect from light. Stock standards should be checked frequently for signs of degradation or evaporation, especially just prior to preparing calibration standards from them.

5.4.3 Stock standard solutions must be replaced after one year, or sooner if comparison with check standards indicates a problem.

5.5 Calibration standards: Calibration standards at a minimum of five concentrations for each parameter of interest are prepared through dilution of the stock standards with isooctane. One of the concentrations should be at a concentration near, but above, the method detection limit. The remaining concentrations should correspond to the expected range of concentrations found in real samples or should define the working range of the GC. Calibration solutions must be replaced after six months, or sooner, if comparison with check standards indicates a problem.

5.6 Internal standards (if internal standard calibration is used): To use this approach, the analyst must select one or more internal standards that are similar in analytical behavior to the compounds of interest. The analyst must further demonstrate that the measurement of the internal standard is not affected by method or matrix interferences. Because of these limitations, no internal standard can be suggested that is applicable to all samples.

5.6.1 Prepare calibration standards at a minimum of five concentrations for each analyte of interest as described in Sec. 5.5.

5.6.2 To each calibration standard, add a known constant amount of one or more internal standards, and dilute to volume with isooctane.

5.6.3 Analyze each calibration standard according to Sec. 7.0.

5.7 Surrogate standards: The analyst should monitor the performance of the extraction, cleanup (when used), and analytical system and the effectiveness of the method in dealing with each sample matrix by spiking each sample, standard, and organic-free reagent water blank with pesticide surrogates. Because GC/ECD data are much more subject to interference than GC/MS, a secondary surrogate is to be used when sample interference is apparent. Two surrogate standards (tetrachloro-m-xylene (TCMX) and decachlorobiphenyl) are added to each sample; however, only one need be calculated for recovery. Proceed with corrective action when both surrogates are out of limits for a sample (Sec. 8.3). Method 3500 indicates the proper procedure for preparing these surrogates.

## 6.0 SAMPLE COLLECTION, PRESERVATION, AND HANDLING

6.1 See the introductory material to this chapter, Organic Analytes, Sec. 4.1. Extracts must be stored under refrigeration and analyzed within 40 days of extraction.

## 7.0 PROCEDURE

### 7.1 Extraction:

7.1.1 Refer to Chapter Two for guidance on choosing the appropriate extraction procedure. In general, water samples are extracted at a neutral, or as is, pH with methylene chloride, using either Method 3510 or 3520. Solid samples are extracted using Method 3540, 3541, or 3550.

7.1.2 Prior to gas chromatographic analysis, the extraction solvent must be exchanged to hexane. The exchange is performed during the K-D procedures listed in all of the extraction methods. The exchange is performed as follows.

7.1.2.1 Following K-D of the methylene chloride extract to 1 mL using the macro-Snyder column, allow the apparatus to cool and drain for at least 10 min.

7.1.2.2 Increase the temperature of the hot water bath to about 90°C. Momentarily remove the Snyder column, add 50 mL of hexane, a new boiling chip, and reattach the macro-Snyder column. Concentrate the extract using 1 mL of hexane to prewet the Snyder column. Place the K-D apparatus on the water bath so that the concentrator tube is partially immersed in the hot water. Adjust the vertical position of the apparatus and the water temperature, as required, to complete concentration in 5-10 min. At the proper rate of distillation the balls of the column will actively chatter, but the chambers will not flood. When the apparent volume of liquid

reaches 1 mL, remove the K-D apparatus and allow it to drain and cool for at least 10 min.

7.1.2.3 Remove the Snyder column and rinse the flask and its lower joint into the concentrator tube with 1-2 mL of hexane. A 5 mL syringe is recommended for this operation. Adjust the extract volume to 10.0 mL. Stopper the concentrator tube and store refrigerated at 4°C, if further processing will not be performed immediately. If the extract will be stored longer than two days, it should be transferred to a vial with a Teflon-lined screw cap or crimp top. Proceed with gas chromatographic analysis if further cleanup is not required.

## 7.2 Gas chromatography conditions (Recommended):

### 7.2.1 Column 1:

Carrier gas (5% methane/95% argon) flow rate: 60 mL/min  
Column temperature: 200°C isothermal

When analyzing for the low molecular weight PCBs (PCB 1221-PCB 1248), it is advisable to set the oven temperature to 160°C.

### 7.2.2 Column 2:

Carrier gas (5% methane/95% argon) flow rate: 60 mL/min  
Column temperature: 200°C isothermal

When analyzing for the low molecular weight PCBs (PCB 1221-PCB 1248), it is advisable to set the oven temperature to 140°C.

7.2.3 When analyzing for most or all of the analytes in this method, adjust the oven temperature and column gas flow to provide sufficient resolution for accurate quantitation of the analytes. This will normally result in a retention time of 10 to 12 minutes for 4,4'-DDT, depending on the packed column used.

7.3 Calibration: Refer to Method 8000 for proper calibration techniques. Use Table 1 and especially Table 2 for guidance on selecting the lowest point on the calibration curve.

7.3.1 The procedure for internal or external calibration may be used. Refer to Method 8000 for a description of each of these procedures.

7.3.2 Because of the low concentration of pesticide standards injected on a GC/ECD, column adsorption may be a problem when the GC has not been used for a day. Therefore, the GC column should be primed or deactivated by injecting a PCB or pesticide standard mixture approximately 20 times more concentrated than the mid-concentration standard. Inject this prior to beginning initial or daily calibration.

#### 7.4 Gas chromatographic analysis:

7.4.1 Refer to Method 8000. If the internal standard calibration technique is used, add 10  $\mu$ L of internal standard to the sample prior to injection.

7.4.2 Method 8000 provides instructions on the analysis sequence, appropriate dilutions, establishing daily retention time windows, and identification criteria. Include a mid-concentration standard after each group of 10 samples in the analysis sequence.

NOTE: A 72 hour sequence is not required with this method.

7.4.3 Examples of GC/ECD chromatograms for various pesticides and PCBs are shown in Figures 1 through 5.

7.4.4 Prime the column as per Sec. 7.3.2.

7.4.5 DDT and endrin are easily degraded in the injection port if the injection port or front of the column is dirty. This is the result of buildup of high boiling residue from sample injection. Check for degradation problems by injecting a mid-concentration standard containing only 4,4'-DDT and endrin. Look for the degradation products of 4,4'-DDT (4,4'-DDE and 4,4'-DDD) and endrin (endrin ketone and endrin aldehyde). If degradation of either DDT or endrin exceeds 20%, take corrective action before proceeding with calibration, by following the GC system maintenance outlined in of Method 8000. Calculate percent breakdown as follows:

$$\begin{array}{l} \text{\% breakdown} \\ \text{for 4,4'-DDT} \end{array} = \frac{\text{Total DDT degradation peak area (DDE + DDD)}}{\text{Total DDT peak area (DDT + DDE + DDD)}} \times 100$$

$$\begin{array}{l} \text{\% breakdown} \\ \text{for Endrin} \end{array} = \frac{\text{Total endrin degradation peak area} \\ \text{(endrin aldehyde + endrin ketone)}}{\text{Total endrin peak area (endrin +} \\ \text{endrin aldehyde + endrin ketone)}} \times 100$$

7.4.6 Record the sample volume injected and the resulting peak sizes (in area units or peak heights).

7.4.7 Using either the internal or external calibration procedure (Method 8000), determine the identity and quantity of each component peak in the sample chromatogram which corresponds to the compounds used for calibration purposes.

7.4.8 If peak detection and identification are prevented due to interferences, the hexane extract may need to undergo cleanup using Method 3620. The resultant extract(s) may be analyzed by GC directly or may undergo further cleanup to remove sulfur using Method 3660.



## 7.5 Cleanup:

7.5.1 Proceed with Method 3620, followed by, if necessary, Method 3660, using the 10 mL hexane extracts obtained from Sec. 7.1.2.3.

7.5.2 Following cleanup, the extracts should be analyzed by GC, as described in the previous sections and in Method 8000.

7.5.3 If only PCBs are to be measured in a sample, the sulfuric acid/permanganate cleanup (Method 3665), followed by Silica Cleanup (Method 3630) or Florisil Cleanup (Method 3620), is recommended.

## 7.6 Calculations (excerpted from U.S. FDA, PAM):

7.6.1 Calculation of Certain Residues: Residues which are mixtures of two or more components present problems in measurement. When they are found together, e.g., toxaphene and DDT, the problem of quantitation becomes even more difficult. In the following sections suggestions are offered for handling toxaphene, chlordane, PCB, DDT, and BHC. A 10% DC-200 stationary phase column was used to obtain the chromatograms in Figures 6-9.

7.6.2 Toxaphene: Quantitative calculation of toxaphene or Strobane is difficult, but reasonable accuracy can be obtained. To calculate toxaphene on GC/ECD: (a) adjust sample size so that toxaphene major peaks are 10-30% full-scale deflection (FSD); (b) inject a toxaphene standard that is estimated to be within  $\pm 10$  ng of the sample; (c) construct the baseline of standard toxaphene between its extremities; and (d) construct the baseline under the sample, using the distances of the peak troughs to baseline on the standard as a guide (Figures 7, 8, and 9). This procedure is made difficult by the fact that the relative heights and widths of the peaks in the sample will probably not be identical to the standard. A toxaphene standard that has been passed through a Florisil column will show a shorter retention time for peak X and an enlargement of peak Y.

7.6.3 Toxaphene and DDT: If DDT is present, it will superimpose itself on toxaphene peak V. To determine the approximate baseline of the DDT, draw a line connecting the trough of peaks U and V with the trough of peaks W and X and construct another line parallel to this line which will just cut the top of peak W (Figure 61). This procedure was tested with ratios of standard toxaphene-DDT mixtures from 1:10 to 2:1 and the results of added and calculated DDT and toxaphene by the "parallel lines" method of baseline construction were within 10% of the actual values in all cases.

7.6.3.1 A series of toxaphene residues have been calculated using total peak area for comparison to the standard and also using area of the last four peaks only in both sample and standard. The agreement between the results obtained by the two methods justifies the use of the latter method for calculating toxaphene in a sample where the early eluting portion of the toxaphene chromatogram is interfered with by other substances.

7.6.3.2 The baseline for methoxychlor superimposed on toxaphene (Figure 8b) was constructed by overlaying the samples on a toxaphene standard of approximately the same concentration (Figure 8a) and viewing the charts against a lighted background.

7.6.4 Chlordane is a technical mixture of at least 11 major components and 30 or more minor ones. Gas chromatography-mass spectrometry and nuclear magnetic resonance analytical techniques have been applied to the elucidation of the chemical structures of the many chlordane constituents. Figure 9a is a chromatogram of standard chlordane. Peaks E and F are responses to trans- and cis-chlordane, respectively. These are the two major components of technical chlordane, but the exact percentage of each in the technical material is not completely defined and is not consistent from batch to batch. Other labelled peaks in Figure 9a are thought to represent: A, monochlorinated adduct of pentachlorocyclopentadiene with cyclopentadiene; B, coelution of heptachlor and  $\alpha$ -chlordene; C, coelution of  $\beta$ -chlordene and  $\gamma$ -chlordene; D, a chlordane analog; G, coelution of cis-nonachlor and "Compound K," a chlordane isomer. The right "shoulder" of peak F is caused by trans-nonachlor.

7.6.4.1 The GC pattern of a chlordane residue may differ considerably from that of the technical standard. Depending on the sample substrate and its history, residues of chlordane can consist of almost any combination of constituents from the technical chlordane, plant and/or animal metabolites, and products of degradation caused by exposure to environmental factors such as water and sunlight. Only limited information is available on which residue GC patterns are likely to occur in which samples types, and even this information may not be applicable to a situation where the route of exposure is unusual. For example, fish exposed to a recent spill of technical chlordane will contain a residue drastically different from a fish whose chlordane residue was accumulated by ingestion of smaller fish or of vegetation, which in turn had accumulated residues because chlordane was in the water from agricultural runoff.

7.6.4.2 Because of this inability to predict a chlordane residue GC pattern, it is not possible to prescribe a single method for the quantitation of chlordane residues. The analyst must judge whether or not the residue's GC pattern is sufficiently similar to that of a technical chlordane reference material to use the latter as a reference standard for quantitation.

7.6.4.3 When the chlordane residue does not resemble technical chlordane, but instead consists primarily of individual, identifiable peaks, quantitate each peak separately against the appropriate reference materials and report the individual residues. (Reference materials are available for at least 11 chlordane constituents, metabolites or degradation products which may occur in the residue.)

7.6.4.4 When the GC pattern of the residue resembles that of technical chlordane, quantitate chlordane residues by comparing the total area of the chlordane chromatogram from peaks A through F (Figure 9a) in the sample versus the same part of the standard chromatogram. Peak G may be obscured in a sample by the presence of other pesticides. If G is not obscured, include it in the measurement for both standard and sample. If the heptachlor epoxide peak is relatively small, include it as part of the total chlordane area for calculation of the residue. If heptachlor and/or heptachlor epoxide are much out of proportion as in Figure 6j, calculate these separately and subtract their areas from total area to give a corrected chlordane area. (Note that octachlor epoxide, a metabolite of chlordane, can easily be mistaken for heptachlor epoxide on a nonpolar GC column.)

7.6.4.5 To measure the total area of the chlordane chromatogram, proceed as in Sec. 7.6.2 on toxaphene. Inject an amount of technical chlordane standard which will produce a chromatogram in which peaks E and F are approximately the same size as those in the sample chromatograms. Construct the baseline beneath the standard from the beginning of peak A to the end of peak F as shown in Figure 9a. Use the distance from the trough between peaks E and F to the baseline in the chromatogram of the standard to construct the baseline in the chromatogram of the sample. Figure 9b shows how the presence of toxaphene causes the baseline under chlordane to take an upward angle. When the size of peaks E and F in standard and sample chromatograms are the same, the distance from the trough of the peaks to the baselines should be the same. Measurement of chlordane area should be done by total peak area if possible.

NOTE: A comparison has been made of the total peak area integration method and the addition of peak heights method for several samples containing chlordane. The peak heights A, B, C, D, E, and F were measured in millimeters from peak maximum of each to the baseline constructed under the total chlordane area and were then added together. These results obtained by the two techniques are too close to ignore this method of "peak height addition" as a means of calculating chlordane. The technique has inherent difficulties because not all the peaks are symmetrical and not all are present in the same ratio in standard and in sample. This method does offer a means of calculating results if no means of measuring total area is practical.

7.6.5 Polychlorinated biphenyls (PCBs): Quantitation of residues of PCB involves problems similar to those encountered in the quantitation of toxaphene, Strobane, and chlordane. In each case, the chemical is made up of numerous compounds. So the chromatograms are multi-peak. Also in each case, the chromatogram of the residue may not match that of the standard.

7.6.5.1 Mixtures of PCBs of various chlorine contents were sold for many years in the U.S. by the Monsanto Co. under the

tradename Aroclor (1200 series and 1016). Though these Aroclors are no longer marketed, the PCBs remain in the environment and are sometimes found as residues in foods, especially fish.

7.6.5.2 PCB residues are quantitated by comparison to one or more of the Aroclor materials, depending on the chromatographic pattern of the residue. A choice must be made as to which Aroclor or mixture of Aroclors will produce a chromatogram most similar to that of the residue. This may also involve a judgment about what proportion of the different Aroclors to combine to produce the appropriate reference material.

7.6.5.3 Quantitate PCB residues by comparing total area or height of residue peaks to total area or height of peaks from appropriate Aroclor(s) reference materials. Measure total area or height response from common baseline under all peaks. Use only those peaks from the sample that can be attributed to chlorobiphenyls. These peaks must also be present in the chromatogram of the reference materials. Mixtures of Aroclors may be required to provide the best match of GC patterns of sample and reference.

7.6.6 DDT: DDT found in samples often consists of both o,p'- and p,p'-DDT. Residues of DDE and DDD are also frequently present. Each isomer of DDT and its metabolites should be quantitated using the pure standard of that compound and reported as such.

7.6.7 Hexachlorocyclohexane (BHC, from the former name, benzene hexachloride): Technical grade BHC is a cream-colored amorphous solid with a very characteristic musty odor; it consists of a mixture of six chemically distinct isomers and one or more heptachloro-cyclohexanes and octachloro-cyclohexanes.

7.6.7.1 Commercial BHC preparations may show a wide variance in the percentage of individual isomers present. The elimination rate of the isomers fed to rats was 3 weeks for the  $\alpha$ -,  $\gamma$ -, and  $\delta$ -isomers and 14 weeks for the  $\beta$ -isomer. Thus it may be possible to have any combination of the various isomers in different food commodities. BHC found in dairy products usually has a large percentage of  $\beta$ -isomer.

7.6.7.2 Individual isomers ( $\alpha$ ,  $\beta$ ,  $\gamma$ , and  $\delta$ ) were injected into gas chromatographs equipped with flame ionization, microcoulometric, and electron capture detectors. Response for the four isomers is very nearly the same whether flame ionization or microcoulometric GLC is used. The  $\alpha$ -,  $\gamma$ -, and  $\delta$ -isomers show equal electron affinity.  $\beta$ -BHC shows a much weaker electron affinity compared to the other isomers.

7.6.7.3 Quantitate each isomer ( $\alpha$ ,  $\beta$ ,  $\gamma$ , and  $\delta$ ) separately against a standard of the respective pure isomer, using a GC column which separates all the isomers from one another.

## 8.0 QUALITY CONTROL

8.1 Refer to Chapter One for specific quality control procedures. Quality control to validate sample extraction is covered in Method 3500 and in the extraction method utilized. If extract cleanup was performed, follow the QC in Method 3600 and in the specific cleanup method.

8.2 Quality control required to evaluate the GC system operation is found in Method 8000.

8.2.1 The quality control check sample concentrate (Method 8000) should contain each single-component parameter of interest at the following concentrations in acetone or other water miscible solvent: 4,4'-DDD, 10 mg/L; 4,4'-DDT, 10 mg/L; endosulfan II, 10 mg/L; endosulfan sulfate, 10 mg/L; endrin, 10 mg/L; and any other single-component pesticide, 2 mg/L. If this method is only to be used to analyze for PCBs, chlordane, or toxaphene, the QC check sample concentrate should contain the most representative multi-component parameter at a concentration of 50 mg/L in acetone.

8.2.2 Table 3 indicates the QC acceptance criteria for this method. Table 4 gives method accuracy and precision as functions of concentration for the analytes of interest. The contents of both Tables should be used to evaluate a laboratory's ability to perform and generate acceptable data by this method.

8.3 Calculate surrogate standard recovery on all samples, blanks, and spikes. Determine if the recovery is within limits (limits established by performing QC procedures outlined in Method 8000).

8.3.1 If recovery is not within limits, the following is required.

- Check to be sure there are no errors in calculations, surrogate solutions and internal standards. Also, check instrument performance.
- Recalculate the data and/or reanalyze the extract if any of the above checks reveal a problem.
- Reextract and reanalyze the sample if none of the above are a problem or flag the data as "estimated concentration".

8.4 GC/MS confirmation: Any compounds confirmed by two columns may also be confirmed by GC/MS if the concentration is sufficient for detection by GC/MS as determined by the laboratory generated detection limits.

8.4.1 The GC/MS would normally require a minimum concentration of 10 ng/ $\mu$ L in the final extract, for each single-component compound.

8.4.2 The pesticide extract and associated blank should be analyzed by GC/MS as per Sec. 7.0 of Method 8270.

8.4.3 The confirmation may be from the GC/MS analysis of the base/neutral-acid extractables extracts (sample and blank). However, if the compounds are not detected in the base/neutral-acid extract even though the concentration is high enough, a GC/MS analysis of the pesticide extract should be performed.

8.4.4 A reference standard of the compound must also be analyzed by GC/MS. The concentration of the reference standard must be at a level that would demonstrate the ability to confirm the pesticides/PCBs identified by GC/ECD.

## 9.0 METHOD PERFORMANCE

9.1 The method was tested by 20 laboratories using organic-free reagent water, drinking water, surface water, and three industrial wastewaters spiked at six concentrations. Concentrations used in the study ranged from 0.5 to 30  $\mu\text{g/L}$  for single-component pesticides and from 8.5 to 400  $\mu\text{g/L}$  for multi-component parameters. Single operator precision, overall precision, and method accuracy were found to be directly related to the concentration of the parameter and essentially independent of the sample matrix. Linear equations to describe these relationships for an electron capture detector are presented in Table 4.

9.2 The accuracy and precision obtained will be determined by the sample matrix, sample-preparation technique, optional cleanup techniques, and calibration procedures used.

## 10.0 REFERENCES

1. U.S. EPA, "Development and Application of Test Procedures for Specific Organic Toxic Substances in Wastewaters, Category 10: Pesticides and PCBs," Report for EPA Contract 68-03-2605.
2. U.S. EPA, "Interim Methods for the Sampling and Analysis of Priority Pollutants in Sediments and Fish Tissue," Environmental Monitoring and Support Laboratory, Cincinnati, OH 45268, October 1980.
3. Pressley, T.A., and J.E. Longbottom, "The Determination of Organohalide Pesticides and PCBs in Industrial and Municipal Wastewater: Method 617," U.S. EPA/EMSL, Cincinnati, OH, EPA-600/4-84-006, 1982.
4. "Determination of Pesticides and PCB's in Industrial and Municipal Wastewaters, U.S. Environmental Protection Agency," Environmental Monitoring and Support Laboratory, Cincinnati, OH 45268, EPA-600/4-82-023, June 1982.
5. Goerlitz, D.F. and L.M. Law, Bulletin for Environmental Contamination and Toxicology, 6, 9, 1971.
6. Burke, J.A., "Gas Chromatography for Pesticide Residue Analysis; Some Practical Aspects," Journal of the Association of Official Analytical Chemists, 48, 1037, 1965.

7. Webb, R.G. and A.C. McCall, "Quantitative PCB Standards for Electron Capture Gas Chromatography," *Journal of Chromatographic Science*, 11, 366, 1973.
8. Millar, J.D., R.E. Thomas and H.J. Schattenberg, "EPA Method Study 18, Method 608: Organochlorine Pesticides and PCBs," U.S. EPA/EMSL, Research Triangle Park, NC, EPA-600/4-84-061, 1984.
9. U.S. EPA 40 CFR Part 136, "Guidelines Establishing Test Procedures for the Analysis of Pollutants Under the Clean Water Act; Final Rule and Interim Final Rule and Proposed Rule," October 26, 1984.
11. U.S. Food and Drug Administration, *Pesticide Analytical Manual*, Vol. 1, June 1979.
12. Sawyer, L.D., *JAOAC*, 56, 1015-1023 (1973), 61 272-281 (1978), 61 282-291 (1978).
13. Stewart, J. "EPA Verification Experiment for Validation of the SOXTEC<sup>®</sup> PCB Extraction Procedure"; Oak Ridge National Laboratory, Oak Ridge, TN, 37831-6138; October 1988.

TABLE 1.  
GAS CHROMATOGRAPHY OF PESTICIDES AND PCBs\*

Analyte	Retention time (min)		Method Detection limit ( $\mu\text{g/L}$ )
	Col. 1	Col. 2	
Aldrin	2.40	4.10	0.004
$\alpha$ -BHC	1.35	1.82	0.003
$\beta$ -BHC	1.90	1.97	0.006
$\delta$ -BHC	2.15	2.20	0.009
$\gamma$ -BHC (Lindane)	1.70	2.13	0.004
Chlordane (technical)	e	e	0.014
4,4'-DDD	7.83	9.08	0.011
4,4'-DDE	5.13	7.15	0.004
4,4'-DDT	9.40	11.75	0.012
Dieldrin	5.45	7.23	0.002
Endosulfan I	4.50	6.20	0.014
Endosulfan II	8.00	8.28	0.004
Endosulfan sulfate	14.22	10.70	0.066
Endrin	6.55	8.10	0.006
Endrin aldehyde	11.82	9.30	0.023
Heptachlor	2.00	3.35	0.003
Heptachlor epoxide	3.50	5.00	0.083
Methoxychlor	18.20	26.60	0.176
Toxaphene	e	e	0.24
PCB-1016	e	e	nd
PCB-1221	e	e	nd
PCB-1232	e	e	nd
PCB-1242	e	e	0.065
PCB-1248	e	e	nd
PCB-1254	e	e	nd
PCB-1260	e	e	nd

\*U.S. EPA. Method 617. Organochlorine Pesticides and PCBs. Environmental Monitoring and Support Laboratory, Cincinnati, Ohio 45268.

e = Multiple peak response.

nd = not determined.



TABLE 2.  
DETERMINATION OF ESTIMATED QUANTITATION LIMITS (EQLs) FOR VARIOUS MATRICES<sup>a</sup>

Matrix	Factor
Ground water	10
Low-concentration soil by sonication with GPC cleanup	670
High-concentration soil and sludges by sonication	10,000
Non-water miscible waste	100,000

a EQL = [Method detection limit (see Table 1)] X [Factor found in this table]. For non-aqueous samples, the factor is on a wet-weight basis. Sample EQLs are highly matrix-dependent. The EQLs listed herein are provided for guidance and may not always be achievable.

TABLE 3.  
QC ACCEPTANCE CRITERIA\*

Analyte	Test conc. ( $\mu\text{g/L}$ )	Limit for s ( $\mu\text{g/L}$ )	Range for $\bar{x}$ ( $\mu\text{g/L}$ )	Range P, P <sub>s</sub> (%)
Aldrin	2.0	0.42	1.08-2.24	42-122
$\alpha$ -BHC	2.0	0.48	0.98-2.44	37-134
$\beta$ -BHC	2.0	0.64	0.78-2.60	17-147
$\delta$ -BHC	2.0	0.72	1.01-2.37	19-140
$\gamma$ -BHC	2.0	0.46	0.86-2.32	32-127
Chlordane	50	10.0	27.6-54.3	45-119
4,4'-DDD	10	2.8	4.8-12.6	31-141
4,4'-DDE	2.0	0.55	1.08-2.60	30-145
4,4'-DDT	10	3.6	4.6-13.7	25-160
Dieldrin	2.0	0.76	1.15-2.49	36-146
Endosulfan I	2.0	0.49	1.14-2.82	45-153
Endosulfan II	10	6.1	2.2-17.1	D-202
Endosulfan Sulfate	10	2.7	3.8-13.2	26-144
Endrin	10	3.7	5.1-12.6	30-147
Heptachlor	2.0	0.40	0.86-2.00	34-111
Heptachlor epoxide	2.0	0.41	1.13-2.63	37-142
Toxaphene	50	12.7	27.8-55.6	41-126
PCB-1016	50	10.0	30.5-51.5	50-114
PCB-1221	50	24.4	22.1-75.2	15-178
PCB-1232	50	17.9	14.0-98.5	10-215
PCB-1242	50	12.2	24.8-69.6	39-150
PCB-1248	50	15.9	29.0-70.2	38-158
PCB-1254	50	13.8	22.2-57.9	29-131
PCB-1260	50	10.4	18.7-54.9	8-127

s = Standard deviation of four recovery measurements, in  $\mu\text{g/L}$ .

$\bar{x}$  = Average recovery for four recovery measurements, in  $\mu\text{g/L}$ .

P, P<sub>s</sub> = Percent recovery measured.

D = Detected; result must be greater than zero.

\*Criteria from 40 CFR Part 136 for Method 608. These criteria are based directly upon the method performance data in Table 4. Where necessary, the limits for recovery have been broadened to assure applicability of the limits to concentrations below those used to develop Table 4.

TABLE 4.  
METHOD ACCURACY AND PRECISION AS FUNCTIONS OF CONCENTRATION\*

Analyte	Accuracy, as recovery, $x'$ ( $\mu\text{g/L}$ )	Single analyst precision, $s_r'$ ( $\mu\text{g/L}$ )	Overall precision, $S'$ ( $\mu\text{g/L}$ )
Aldrin	0.81C+0.04	0.16 $\bar{x}$ -0.04	0.20 $\bar{x}$ -0.01
$\alpha$ -BHC	0.84C+0.03	0.13 $\bar{x}$ +0.04	0.23 $\bar{x}$ -0.00
$\beta$ -BHC	0.81C+0.07	0.22 $\bar{x}$ +0.02	0.33 $\bar{x}$ -0.95
$\delta$ -BHC	0.81C+0.07	0.18 $\bar{x}$ +0.09	0.25 $\bar{x}$ +0.03
$\gamma$ -BHC	0.82C-0.05	0.12 $\bar{x}$ +0.06	0.22 $\bar{x}$ +0.04
Chlordane	0.82C-0.04	0.13 $\bar{x}$ +0.13	0.18 $\bar{x}$ +0.18
4,4'-DDD	0.84C+0.30	0.20 $\bar{x}$ -0.18	0.27 $\bar{x}$ -0.14
4,4'-DDE	0.85C+0.14	0.13 $\bar{x}$ +0.06	0.28 $\bar{x}$ -0.09
4,4'-DDT	0.93C-0.13	0.17 $\bar{x}$ +0.39	0.31 $\bar{x}$ -0.21
Dieldrin	0.90C+0.02	0.12 $\bar{x}$ +0.19	0.16 $\bar{x}$ +0.16
Endosulfan I	0.97C+0.04	0.10 $\bar{x}$ +0.07	0.18 $\bar{x}$ +0.08
Endosulfan II	0.93C+0.34	0.41 $\bar{x}$ -0.65	0.47 $\bar{x}$ -0.20
Endosulfan Sulfate	0.89C-0.37	0.13 $\bar{x}$ +0.33	0.24 $\bar{x}$ +0.35
Endrin	0.89C-0.04	0.20 $\bar{x}$ +0.25	0.24 $\bar{x}$ +0.25
Heptachlor	0.69C+0.04	0.06 $\bar{x}$ +0.13	0.16 $\bar{x}$ +0.08
Heptachlor epoxide	0.89C+0.10	0.18 $\bar{x}$ -0.11	0.25 $\bar{x}$ -0.08
Toxaphene	0.80C+1.74	0.09 $\bar{x}$ +3.20	0.20 $\bar{x}$ +0.22
PCB-1016	0.81C+0.50	0.13 $\bar{x}$ +0.15	0.15 $\bar{x}$ +0.45
PCB-1221	0.96C+0.65	0.29 $\bar{x}$ -0.76	0.35 $\bar{x}$ -0.62
PCB-1232	0.91C+10.79	0.21 $\bar{x}$ -1.93	0.31 $\bar{x}$ +3.50
PCB-1242	0.91C+10.79	0.21 $\bar{x}$ -1.93	0.31 $\bar{x}$ +3.50
PCB-1248	0.91C+10.79	0.21 $\bar{x}$ -1.93	0.31 $\bar{x}$ +3.50
PCB-1254	0.91C+10.79	0.21 $\bar{x}$ -1.93	0.31 $\bar{x}$ +3.50
PCB-1260	0.91C+10.79	0.21 $\bar{x}$ -1.93	0.31 $\bar{x}$ +3.50

- $x'$  = Expected recovery for one or more measurements of a sample containing concentration C, in  $\mu\text{g/L}$ .
- $s_r'$  = Expected single analyst standard deviation of measurements at an average concentration of  $\bar{x}$ , in  $\mu\text{g/L}$ .
- $S'$  = Expected interlaboratory standard deviation of measurements at an average concentration found of  $\bar{x}$ , in  $\mu\text{g/L}$ .
- C = True value for the concentration, in  $\mu\text{g/L}$ .
- $\bar{x}$  = Average recovery found for measurements of samples containing a concentration of C, in  $\mu\text{g/L}$ .

Figure 1  
Gas Chromatogram of Pesticides




Figure 2  
Gas Chromatogram of Chlordane




Figure 3  
Gas Chromatogram of Toxaphene




Figure 4  
Gas Chromatogram of Aroclor 1254




Figure 5  
Gas Chromatogram of Aroclor 1260






Figure 6




Fig.6--Baseline construction for some typical gas chromatographic peaks.  
 a: symmetrical separated flat baseline; b and c: overlapp flat baseline;  
 d: separated (pen does not return to baseline between peaks); e: separated  
 sloping baseline; f: separated (pen goes below baseline between peaks);  
 g:  $\alpha$ - and  $\gamma$ -BHC sloping baseline; h:  $\alpha$ -,  $\beta$ - and  $\gamma$ -BHC sloping baseline;  
 i: chlordane flat baseline; j: heptachlor and heptachlor epoxide super-  
 imposed on chlordane; k: chair-shaped peaks, unsymmetrical peak;  
 l: p,p'-DDT superimposed on toxaphene.

Figure 7




Fig.- 7a -- Baseline construction for multiple residues with standard toxaphene.




Fig.- 7b -- Baseline construction for multiple residues with toxaphene, DDE and o,p'-, and p,p'-DDT

Figure 8




Fig.- 8a -- Baseline construction for multiple residues: standard toxaphene.




Fig.- 8b -- Baseline construction for multiple residues: rice bran with BHC, toxaphene, DDT, and methoxychlor.

Figure 9




Fig. - 9a -- Baseline construction for multiple





Fig. - 9b -- Baseline construction for multiple  
chlordane, toxaphene, and

METHOD 8080A  
ORGANOCHLORINE PESTICIDES AND POLYCHLORINATED BIPHENYLS  
BY GAS CHROMATOGRAPHY



***APPENDIX C***  
***NEW YORK STATE DEPARTMENT OF HEALTH***  
***METHOD 311-1***

NEW YORK STATE DEPARTMENT OF HEALTH  
WADSWORTH CENTER FOR LABORATORIES AND RESEARCH  
ALBANY, N.Y. 12201

10/6/81

POLYCHLORINATED BIPHENYLS IN AMBIENT AIR

1. Scope and Application

- 1.1 This method covers the determination of polychlorinated biphenyls (PCBs) as Aroclors 1016/1242, 1221, 1254, 1260 in ambient air.
- 1.2 A 24 hour sample containing Aroclor 1016 collected at approximately 1.0 liter per minute is efficiently trapped in one cartridge, even at 95% relative humidity.
- 1.3 The minimum detectable concentration is 0.033 ug/1.5 ml of extract which is approximately 0.02 ug/cubic meter when sampled for 24 hours at 1 to 2 liters per minute.

2. Summary of Method

- 2.1 Polychlorinated biphenyls are quantitatively trapped on florisil in a cartridge. The PCB is desorbed by extraction with hexane. Sample clean-up is performed, if necessary. Analysis for PCBs is carried out on a gas chromatograph with a 3% SE-30 on GAS-CHROM Q column and electron capture detector. Results are reported in ug/cubic meter.

3. Interferences

- 3.1 Solvents, glassware, and other sample processing hardware may yield discrete artifacts and/or elevated base lines, causing misinterpretation of gas chromatograms. All of these materials must be demonstrated to be free from interferences under the conditions of the analysis. Specific selection of reagents and purification of solvents by distillation in all-glass systems may be required. Refer to Section 510-1, Analytical Handbook.
- 3.2 Organophosphorus pesticides - a number of organophosphorus pesticides, such as those containing a nitro group, e.g., parathion, also respond to the electron capture detector and may interfere with the determination of the organochlorine pesticides. Such compounds can be identified by their response to the flame photometric detector.
- 3.3 Interferences from chlorinated pesticides can be removed, if necessary, according to the method of Trotter.

4. Apparatus and Materials

- 4.1 Pasteur pipets - no. P5180-2, 5-3/4 inch length
- 4.2 Pasteur pipet bulb
- 4.3 Air or nitrogen - for evaporating sample
- 4.4 Vacuum pump - capable of maintaining an air pressure differential greater than 0.8 atmosphere at the desired flow rate
- 4.5 Muffle furnace - equipped with temperature control and indicator
- 4.6 Gas chromatograph:
  - 4.6.1 Electron capture detector
  - 4.6.2 Column dimensions - 6' X 1/4"
  - 4.6.3 3% SE-30 on GAS-CHROM Q, 80/100 mesh, 2 mm I.D., Conditioned at 220 C.
  - 4.6.4 Alternate column - 1.5% OV17/1.95% QF-1, on GAS-CHROM Q, 80/100 mesh
- 4.7 Test tubes - graduated, ground-glass stoppered, 5 or 10 ml size
- 4.8 Tygon tubing - 1/4" I.D., 3/8" O.D. for cartridge connections
- 4.9 Teflon tubing - 7 mm I.D.
- 4.10 Caplugs - size 9/32 in SC (Caplugs Division, Protective Closures Co. Inc., 2150 Elmwood Ave., Buffalo, NY)
- 4.11 Wrist Action Shaker, Burrell.

5. Reagents, Solvents and Standards

- 5.1 Florisil - 60-100 mesh, Fisher Scientific Co., #F-100. Wash Florisil with several portions of hexane and dry on a steambath to remove hexane residue. Place Florisil in a muffle furnace at 320 C overnight. Deactivate the Florisil by shaking 100 grams with 2 ml distilled water for 15 minutes on a mechanical wrist action shaker. Store Florisil in a screw-cap jar.
- 5.2 Glass wool - hexane rinsed
- 5.3 Hexanes - nanograde, Mallinckrodt, no. 4159



- 5.4 PCB standards - (Monsanto) Aroclor 1016, 1221, 1254, 1260. Other Aroclors may be of interest, these are the most common. For each Aroclor of interest prepare the following dilute standards:
- 5.4.1 1 mg/ml stock PCB solution - weigh 100 mg of PCB and place in a 100 ml volumetric flask. Dilute to the mark with hexane.
  - 5.4.2 10 ug/ml PCB solution - dilute 1.0 ml of stock PCB solution to 100 ml with hexane in a volumetric flask.
  - 5.4.3 2.0 ug/ml PCB solution - dilute 1.0 ml of 10 ug/ml PCB solution to 5 ml with hexane in a volumetric flask.
  - 5.4.4 1.0 ug/ml PCB solution - dilute 1.0 ml of 10 ug/ml PCB solution to 10 ml with hexane in a volumetric flask.
  - 5.4.5 0.4 ug/ml PCB solution - dilute 1.0 ml of 10 ug/ml PCB solution to 25 ml with hexane in a volumetric flask.
  - 5.4.6 4.0 ug/ml PCB solution - dilute 2 ml of 10 ug/ml PCB solution to 5 ml with hexane in a volumetric flask.
  - 5.4.7 0.04 ug/ml PCB solution - dilute 0.1 ml of 10 ug/ml PCB solution to 25 ml with hexane in a volumetric flask.

## 6. Quality Control

- 6.1 All reagents must be checked for contamination by GLC prior to use.
- 6.2 At least one blank is analyzed with each batch of cartridges or samples.

## 7. Procedure

### 7.1 Preparation of Sampling Cartridges

NOTE: If a large number of cartridges are to be prepared, it is recommended that a particulate mask and disposable plastic gloves be used.

- 7.1.1 All glassware must be free of PCB. Rinse all glassware with at least 3 separate portions of hexane. Bake glassware for two hours at 350 C. Collect a final hexane rinse and concentrate to 0.5 ml for analysis to verify that all interfering chromatogram peaks are removed.
- 7.1.2 Cut 1" to 1 1/4" from the finely drawn end of a Pasteur pipet using a triangular file. Fire polish the cut end.

- 7.1.3 Place a piece of hexane-rinsed glass wool into a Pasteur pipet. Push it down to the pointed end of the pipet. To the pipet, add about 0.4 grams of Florisil. Place a small plug of hexane-rinsed glass wool at the top of the Florisil. Prepare several sampling cartridges in this manner, including a sufficient number to be used as blank cartridges.
  - 7.1.4 After construction of the cartridge, attach the cartridge outlet to a vacuum hose, keeping the cartridge vertical. Turn on the vacuum pump and tap the side of the cartridge lightly for about five seconds to settle and pack the Florisil. Push the glass wool plug down to the surface of the Florisil to insure close contact. This packing procedure eliminates the need to keep the cartridge vertical during sampling. Store the cartridges in an air-tight container.
  - 7.1.5 Assemble cartridge into a sampling train as shown in Figure 1. One cartridge is usually sufficient to form an efficient sampling train. If a train containing two cartridges in series is desired, connections should be made with a short piece of Teflon tubing, butting the glass tubes, and using Tygon sleeving to prevent leaks. Measure and record the flow rate. Seal the ends of the cartridge train with aluminum foil caps or Caplugs to prevent contamination.
  - 7.1.6 If at all possible, an inlet probe should not be used. If this cannot be avoided, a glass probe should be used. Teflon and Tygon have been found to adsorb PCBs and therefore are not recommended.
  - 7.1.7 The sample should be collected for an appropriate period of time, usually 24 hours. The cartridge train should be resealed with aluminum foil or Caplugs before transporting back to the laboratory.
- 7.2 Analysis of Florisil Cartridges
- 7.2.1 After flow rate measurement, disassemble the sampling train. Label the cartridges.
  - 7.2.2 Elute the PCBs into a graduated 5 or 10 ml test tube with a ground glass stopper using about 5 ml of nanograde hexane, adding the hexane to the inlet of the cartridge. Collect the eluate in the graduated test tube.
  - 7.2.3 Concentrate the extract by nitrogen (HP) stream evaporation to bring the PCB concentration of the extract into working range, usually 1 to 5 ml volume. Place extract into 2 ml capacity vials with injectable caps for use with automated gas chromatograph sampler.

- 7.2.4 Run samples and standards on the gas chromatograph under the following conditions:
- 7.2.4.1 Column temperature - 180 C isothermal for Aroclors 1016/1242, 1221, 1254 and 1260.
  - 7.2.4.2 Detector temperature - electron capture detector, 275 C
  - 7.2.4.3 Inlet temperature - 200 C
  - 7.2.4.4 Carrier gas - nitrogen, 40 ml/min
  - 7.2.4.5 Carrier flow rate - 60 cc/min
  - 7.2.4.6 Injection size - 5 ul for manual injection; 1 ul for automated injection.
- 7.2.5 Blank cartridge content should be subtracted from sample cartridges to determine net Aroclor content. Amounts greater than 0.033 ug Aroclor in the blank cartridge extracts may indicate contamination of the cartridge train either before or after sampling (i.e., glassware contamination).
- 7.2.6 Peaks should be quantitated by area comparisons under specific Aroclor peaks of standards of known amounts.

## 8. Calculations

### 8.1 Air Volume Sampled

$$V = RT/1000$$

where, V = volume of air sampled in cubic meters  
R = air flow rate in liters per minute  
T = time sampled in minutes

### 8.2 ug PCB Collected: Read from standard curve or by proportion to standard on day of run.

$$\text{ug PCB} = (A-B) C$$

where, A = ug/ml PCB in sample extract  
B = ug/ml PCB in blank extract (usually is zero)  
C = ml of hexane extract

### 8.3 Report results as ug/cubic meter in air sampled. Report as either total PCB or specific Aroclor.

9. References


- 9.1 Dell'Acqua, B. NYSDH, In-house experiment.
- 9.2 Giam, C.S., Chan, H.S., Neff, G.S. 1975. Rapid and Inexpensive Method for Detection of Polychlorinated Biphenyls and Phthalates in Air. Analytical Chemistry 47(13): 2319-20.
- 9.3 Trotter, W.J. 1973. Removing the Interference of DDT and its Analogs in the Analysis for Residues of Polychlorinated Biphenyls. Journal of the Association of Official Analytical Chemists 58(3): 461-5.
- 9.4 Determination of Polychlorinated Biphenyls in Ambient Air, NYSDH, Division of Laboratories and Research, Environmental Health Institute, APC method 26., June 1979.
- 9.5 NIOSH Health and Hazard Evaluation Report No. 86-472; p. 18, 19; HETA86-472-1832; Commercial Office Buildings, Boston, MA.

HANDBOOKS(311-1)

July 1980; Corrected January 14, 1981; Corrected March 12, 1981

FIGURE 1

# FLORISIL CARTRIDGE



311-1

# SUNY New Paltz

## Wipe Sample Locations

### **Bliss Hall, Building #22**

#### *Basement*

B4 - Floor Area

#### *First Floor*

103 - Floor Area

119 - Desk

#### *Second Floor*

205 - Desk

216 - Floor Area

#### *Third Floor*

326 - Floor Area

309 - Floor Area

### **Gage Hall, Building #21**

#### *Basement East*

B8 - Floor Area

#### *First Floor East*

105 - Desk

RD's Apartment - Floor Area

#### *First Floor West*

117 - Floor Area

133 Overflow - Desk

#### *Second Floor East*

218 - Desk

221 - Floor Area

#### *Third Floor East*

302 - Floor Area

#### *Third Floor West*

343 - Desk

328 - Desk

### **Scudder Hall, Building #20**

#### *First Floor*

115 - Desk

116 - Desk

112 - Desk

#### *Second Floor*

205 - Floor Area

216 - Desk

230 - Desk

#### *Third Floor*

306 - Desk

309 - Floor Area

### **Capen Hall, Building #9**

#### *First Floor*

110 - Floor Area

#### *Second Floor*

220 - Floor Area

#### *Third Floor*

323 - Desk

318 - Floor Area

# SUNY New Paltz

## PCB Air Sample Locations

### **Bliss Hall, Building #22**

#### *First Floor*

112 Overflow

114

#### *Second Floor*

214

218

230

203

223

### **Gage Hall, Building #21**

#### *First Floor East*

112

#### *Second Floor East*

223

203

#### *Second Floor West*

227

231

225

#### *Third Floor East*

302

305

#### *Third Floor West*

325

### **Scudder Hall, Building #20**

#### *Basement*

B3

#### *First Floor*

107

#### *Second Floor*

209

222

#### *Third Floor*

320

322

328

### **Capen Hall, Building #9**

#### *First Floor*

121

#### *Second Floor*

217

226

#### *Third Floor*

302

311

315

Table 1  
 SUNY New Paltz  
 Wipe Sample Locations

Sample Location	Field ID Number
<b>Bliss Hall, Building #22</b>	
<i>Basement:</i> B4 – Floor Area	W21
<i>First Floor:</i> 103 – Floor Area	W26
119 – Desk	W27
<i>Second Floor:</i> 205 – Desk	W24
216 – Floor Area	W25
<i>Third Floor:</i> 326 – Floor Area	W23
309 – Floor Area	W22
<b>Gage Hall, Building #21</b>	
<i>Basement East:</i> B8 – Floor Area	W19
<i>First Floor East:</i> 105 – Desk	W17
RD's Apartment – Floor Area	W17
<i>First Floor West:</i> 117 – Floor Area	W16
133 Overflow – Desk	W15
<i>Second Floor East:</i> 218 – Desk	W14
221 – Floor Area	W13
<i>Third Floor East</i> 302 – Floor Area	W20
<i>Third Floor West</i> 343 – Desk	W12
328 – Desk	W11
<b>Scudder Hall, Building #20</b>	
<i>First Floor:</i> 115 – Desk	W10
116 – Desk	W9
112 – Desk	W8
<i>Second Floor:</i> 205 – Floor Area	W7
216 – Desk	W6
230 – Desk	W5
<i>Third Floor:</i> 306 – Desk	W3
309 – Floor Area	W4
<b>Capen Hall, Building #9</b>	
<i>First Floor:</i> 110 – Floor Area	W32
<i>Second Floor:</i> 220 – Floor Area	W31
<i>Third Floor:</i> 323 – Desk	W29
318 – Floor Area	W28
Field Blank	W1
Field Blank	W2
Field Blank	W30



Table 2  
 SUNY New Paltz  
 PCB Air Sample Locations

Sample Location	Field ID Number
<b>Bliss Hall, Building #22</b>	
<i>First Floor:</i> 112 Overflow	A20
114	A19
<i>Second Floor:</i> 214	A31A
218	A22
230	A33
203	A30
223	A21
<b>Gage Hall, Building #21</b>	
<i>First Floor East:</i> 112	A30
<i>Second Floor East:</i> 223	A26
203	A10
<i>Second Floor West:</i> 227	A27
231	A29
225	A28
<i>Third Floor East:</i> 302	A12
305	A25
<i>Third Floor West:</i> 325	All
<b>Scudder Hall, Building #20</b>	
<i>Basement:</i> B3	A3
<i>First Floor:</i> 107	A13
<i>Second Floor:</i> 209	A14
222	A15
<i>Third Floor:</i> 320	A18
322	A17
328	A16
<b>Capen Hall, Building #9</b>	
<i>First Floor:</i> 121	A4
<i>Second Floor:</i> 217	A6
226	A5
<i>Third Floor:</i> 302	A7
311	A8
315	A9
Field Blank	A1
Field Blank	A2
Field Blank	A23
Outside Gage Hall	A24

B06 OVERFLOW
B1 OVERFLOW
B2 OVERFLOW
FIELD ID # W21
B3
B4
B5
B6
B7
B8

STAIRS
BATH

NORTH

BLUE BASEMENT

HOUSE NAME
------------


SOUTH

B9
B10
B11
B12 CLOSED
B13
B14
B15
B16
B17 OVERFLOW

BATH
STAIRS

101
102
103
104
105
BATH
110
111
QUEST ROOM

STAIRS
FIELD ID # W26
106
108
107
108
109
DIP. APT

NORTH

HOUSE NAME

BLISS - 1st floor

LOUNGE
--------

Field ID # A20
112 OVERFLOW
113
Field ID # A19
114
BATH
116
120
122
124

P.A. OFFICE
110 OFFICE
113
115
118
FIELD ID # W27
119
121
123
STAIRS

SOUTH

201
202
203
204
205
BATH
210
212
Field ID # A31
214

STAIRS
FIELD ID # A32
202
FIELD ID # W24
203
207
208
209
211
213
215

BLISS 2nd floor

NORTH

HOUSE NAME

---


Field ID # A22
218
220
222
BATH
223
225
FIELD ID # A33
226
228

FIELD ID # W25
216
217
219
221
FIELD ID # A21
224
225
227
229
231

SOUTH

HOUSE NAME

---

301
303
305
307
BATH
310
312
314

STAIRS
302
304
306
308
FIELD ID # W22
309
311
313
315

BLISS 3rd floor

SOUTH

HOUSE NAME

---

--

318
320
322
BATH
FIELD ID # W23
326
328
330
331


316
317
319
321
323
324
325
327
329
STAIRS

NORTH

HOUSE NAME

---

		B1	B2	B3	B4	B5



B6
B7
FIELD ID # W19
B8
B9
B10



			FIELD ID # W18			
STAIRS	101	103	105	107	108	109 OVERFLOW STUDY LOUNGE

109 OVERFLOW	102	104	106			109
				BATH		110
						111
						FIELD ID # A30
						112
				FIELD ID # W17		113
						114
				PD APT.		
				PD OFFICE		
				RA OFFICE		

GAGE - 1st Floor  
EAST -


HOUSE NAME  
\_\_\_\_\_



GAGE - 1st floor

WEST

HOUSE NAME



STAIRS	202	204	206	208	200	210

	FIELD ID # A10					211
201	203	205	207			212
				BATH		213
				214		215
				216		217
				FIELD ID # W14		218
				219		
				220		STAIRS
				FIELD ID # W13		
				221		STUDY LOUNGE
				BATH		FIELD ID # A26
				222		223
				TV LOUNGE		224

GAGE - 3rd floor


EAST -

HOUSE NAME

GAGE - 2nd Floor

WEST - \_\_\_\_\_

HOUSE NAME _____
---------------------



	FIELD ID # A12 AND # W20					
STAIRS	302	304	306	308	308	310

		FIELD ID # A25				311
301	303	305	307			313
				BATH		312
				314		316
				318		317
				316		319
				320		STAIRS
				321		STUDY LOUNGE
				BATH		323
				322		324

GAGE 3rd floor

EAST - \_\_\_\_\_

HOUSE NAME  
\_\_\_\_\_

DAGE - 3rd floor

WEST - \_\_\_\_\_

HOUSE NAME
------------

TV LOUNGE
227
BATH
228
231
233
235
237

FIELD ID # A11
326
328
FIELD ID # W11
328
330
332
334
336
338
338

			FIELD ID # W12	
340	347	348	342	BATH

STAIRS	348	348	347	341	341

SCUDDER BAREMENT

— NORTH

HOUSE NAME

BATH

BO OF
B1
B7
FIELD ID # A 3
B3
B4
B5
B6
B7
B8

LAUNDRY
BATH
5' UCV TO JNF

B0
B10
B11
B12
B13
B14
B16
B18
B17 OVERFLOW


— SOUTH

HOUSE NAME

SCUDGER - 1st floor

NORTH  
HOUSE NAME

STAIRS	101
103	102
105	104
FIELD ID # A13	106
107	108
109	BATH
109	110
DIR. APT.	111
	GUEST ROOM

RA OFFICE	1120F	LUNGEON
DIR. OFFICE	1120F	
113	FIELD ID # W8	
FIELD ID # W10	112	
115	114	
FIELD ID # W9		
116		
117	BATH	
118	118	
119	120	
121	122	
STAIRS	124	

- SOUTH  
HOUSE NAME

SCUDDER - 2nd floor

- NORTH

HOUSE NAME  
\_\_\_\_\_

STAIRS	201
203	202
FIELD ID # W7	204
205	206
207	BATH
208	210
FIELD ID # A14	212
209	211
211	
213	
215	

STAIRS	216	218
FIELD ID # W6	217	220
215	219	FIELD ID # A15
217	221	222
219	223	BATH
221	225	226
223	227	FIELD ID # W5
225	229	230
227	231	231
229		
STAIRS		

NUMBER

- SOUTH

HOUSE NAME  
\_\_\_\_\_



SCUDDER - 3rd Floor

- NORTH

HOUSE NAME
------------

STAIRS	301
302	304
304	305
FIELD ID # W3	307
308	BATH
309	310
FIELD ID # W4	312
309	314
311	
313	
315	

316	318	LIVING
317	FIELD ID # A18	
318	320	
321	FIELD ID # A16	
322	322	
324	BATH	
325	324	
327	FIELD ID # A16	
329	328	
STAIRS	330	
	331	

- SOUTH

HOUSE NAME
------------

OPEN BASEMENT

— NORTH

HOUSE NAME

STAIRS

PHONE-ACTION ROOM

BATH

MARTIN LUTHER KING

MARTIN LUTHER KING

MARTIN LUTHER KING

B4

B5

B6

B7

B8

B9

B10

B11

B12

B13

B14

B15

OFFICE

— SOUTH

HOUSE NAME

BATH

CAPEN - 1st floor

- NORTH

HOUSE NAME

STAIRS

102

103

107

108

101 APT.

101 HC

102 HC

104 HC

100 MC LAUNDRY

BATH

FIELD ID # W32

110

OFFICE

OFFICE

LOUNGE

- SOUTH

HOUSE NAME

09L

113 DAL

115 ORL

116 ORL

117

118

FIELD ID # A4

121

122

STAIRS

RESIDENCE LIFE

BATH

119 PG

120 MC

121 MC

104 MC

1 APEN - 7th Floor

- NORTH

HOUSE NAME

STAIRS
202
203
204
205
206
207
208
209
210
211
212
213
214

215
216
217
218
219
220
BATH
221
222
223
224
225

226
FIELD ID # A8
227
228
229
230
231
232
233
234
235
236
237
238
239
240
241
242
243
244
245
246
247
248
249
250
251
252
253
254
255
256
257
258
259
260
261
262
263
264
265
266
267
268
269
270
271
272
273
274
275
276
277
278
279
280
281
282
283
284
285
286
287
288
289
290
291
292
293
294
295
296
297
298
299
300
301
302
303
304
305
306
307
308
309
310
311
312
313
314
315
316
317
318
319
320
321
322
323
324
325
326
327
328
329
330
331
332
333
334
335
336
337
338
339
340
341
342
343
344
345
346
347
348
349
350
351
352
353
354
355
356
357
358
359
360
361
362
363
364
365
366
367
368
369
370
371
372
373
374
375
376
377
378
379
380
381
382
383
384
385
386
387
388
389
390
391
392
393
394
395
396
397
398
399
400
401
402
403
404
405
406
407
408
409
410
411
412
413
414
415
416
417
418
419
420
421
422
423
424
425
426
427
428
429
430
431
432
433
434
435
436
437
438
439
440
441
442
443
444
445
446
447
448
449
450
451
452
453
454
455
456
457
458
459
460
461
462
463
464
465
466
467
468
469
470
471
472
473
474
475
476
477
478
479
480
481
482
483
484
485
486
487
488
489
490
491
492
493
494
495
496
497
498
499
500
501
502
503
504
505
506
507
508
509
510
511
512
513
514
515
516
517
518
519
520
521
522
523
524
525
526
527
528
529
530
531
532
533
534
535
536
537
538
539
540
541
542
543
544
545
546
547
548
549
550
551
552
553
554
555
556
557
558
559
560
561
562
563
564
565
566
567
568
569
570
571
572
573
574
575
576
577
578
579
580
581
582
583
584
585
586
587
588
589
590
591
592
593
594
595
596
597
598
599
600
601
602
603
604
605
606
607
608
609
610
611
612
613
614
615
616
617
618
619
620
621
622
623
624
625
626
627
628
629
630
631
632
633
634
635
636
637
638
639
640
641
642
643
644
645
646
647
648
649
650
651
652
653
654
655
656
657
658
659
660
661
662
663
664
665
666
667
668
669
670
671
672
673
674
675
676
677
678
679
680
681
682
683
684
685
686
687
688
689
690
691
692
693
694
695
696
697
698
699
700
701
702
703
704
705
706
707
708
709
710
711
712
713
714
715
716
717
718
719
720
721
722
723
724
725
726
727
728
729
730
731
732
733
734
735
736
737
738
739
740
741
742
743
744
745
746
747
748
749
750
751
752
753
754
755
756
757
758
759
760
761
762
763
764
765
766
767
768
769
770
771
772
773
774
775
776
777
778
779
780
781
782
783
784
785
786
787
788
789
790
791
792
793
794
795
796
797
798
799
800
801
802
803
804
805
806
807
808
809
810
811
812
813
814
815
816
817
818
819
820
821
822
823
824
825
826
827
828
829
830
831
832
833
834
835
836
837
838
839
840
841
842
843
844
845
846
847
848
849
850
851
852
853
854
855
856
857
858
859
860
861
862
863
864
865
866
867
868
869
870
871
872
873
874
875
876
877
878
879
880
881
882
883
884
885
886
887
888
889
890
891
892
893
894
895
896
897
898
899
900
901
902
903
904
905
906
907
908
909
910
911
912
913
914
915
916
917
918
919
920
921
922
923
924
925
926
927
928
929
930
931
932
933
934
935
936
937
938
939
940
941
942
943
944
945
946
947
948
949
950
951
952
953
954
955
956
957
958
959
960
961
962
963
964
965
966
967
968
969
970
971
972
973
974
975
976
977
978
979
980
981
982
983
984
985
986
987
988
989
990
991
992
993
994
995
996
997
998
999
1000

LOU/ROF

- SOUTH

HOUSE NAME

218
FIELD ID # W31
220
221
222
BATH
FIELD ID # A5
224
225
226
227
228
229
230
231
232
233
234
235
236
237
238
239
240
241
242
243
244
245
246
247
248
249
250
251
252
253
254
255
256
257
258
259
260
261
262
263
264
265
266
267
268
269
270
271
272
273
274
275
276
277
278
279
280
281
282
283
284
285
286
287
288
289
290
291
292
293
294
295
296
297
298
299
300
301
302
303
304
305
306
307
308
309
310
311
312
313
314
315
316
317
318
319
320
321
322
323
324
325
326
327
328
329
330
331
332
333
334
335
336
337
338
339
340
341
342
343
344
345
346
347
348
349
350
351
352
353
354
355
356
357
358
359
360
361
362
363
364
365
366
367
368
369
370
371
372
373
374
375
376
377
378
379
380
381
382
383
384
385
386
387
388
389
390
391
392
393
394
395
396
397
398
399
400
401
402
403
404
405
406
407
408
409
410
411
412
413
414
415
416

CAPEN - 3rd floor

- NORTH

HOUSE NAME

STAIRS	301
FIELD ID # A7	
302	303
304	305
306	307
308	BATH
309	310
FIELD ID # A8	312
311	
313	314
FIELD ID # A9	
315	

		LOUNGE
316		
317		
318		
321		
FIELD ID # W29		
323		
324		
325		
327		
329		
330		
331		
332		
333		
334		
335		
336		
337		
338		
339		
340		
341		
342		
343		
344		
345		
346		
347		
348		
349		
350		
351		
352		
353		
354		
355		
356		
357		
358		
359		
360		
361		
362		
363		
364		
365		
366		
367		
368		
369		
370		
371		
372		
373		
374		
375		
376		
377		
378		
379		
380		
381		
382		
383		
384		
385		
386		
387		
388		
389		
390		
391		
392		
393		
394		
395		
396		
397		
398		
399		
400		
401		
402		
403		
404		
405		
406		
407		
408		
409		
410		
411		
412		
413		
414		
415		
416		
417		
418		
419		
420		
421		
422		
423		
424		
425		
426		
427		
428		
429		
430		
431		
432		
433		
434		
435		
436		
437		
438		
439		
440		
441		
442		
443		
444		
445		
446		
447		
448		
449		
450		
451		
452		
453		
454		
455		
456		
457		
458		
459		
460		
461		
462		
463		
464		
465		
466		
467		
468		
469		
470		
471		
472		
473		
474		
475		
476		
477		
478		
479		
480		
481		
482		
483		
484		
485		
486		
487		
488		
489		
490		
491		
492		
493		
494		
495		
496		
497		
498		
499		
500		
501		
502		
503		
504		
505		
506		
507		
508		
509		
510		
511		
512		
513		
514		
515		
516		
517		
518		
519		
520		
521		
522		
523		
524		
525		
526		
527		
528		
529		
530		
531		
532		
533		
534		
535		
536		
537		
538		
539		
540		
541		
542		
543		
544		
545		
546		
547		
548		
549		
550		
551		
552		
553		
554		
555		
556		
557		
558		
559		
560		
561		
562		
563		
564		
565		
566		
567		
568		
569		
570		
571		
572		
573		
574		
575		
576		
577		
578		
579		
580		
581		
582		
583		
584		
585		
586		
587		
588		
589		
590		
591		
592		
593		
594		
595		
596		
597		
598		
599		
600		
601		
602		
603		
604		
605		
606		
607		
608		
609		
610		
611		
612		
613		
614		
615		
616		
617		
618		
619		
620		
621		
622		
623		
624		
625		
626		
627		
628		
629		
630		
631		
632		
633		
634		
635		
636		
637		
638		
639		
640		
641		
642		
643		
644		
645		
646		
647		
648		
649		
650		
651		
652		
653		
654		
655		
656		
657		
658		
659		
660		
661		
662		
663		
664		
665		
666		
667		
668		
669		
670		
671		
672		
673		
674		
675		
676		
677		
678		
679		
680		
681		
682		
683		
684		
685		
686		
687		
688		
689		
690		
691		
692		
693		
694		
695		
696		
697		
698		
699		
700		
701		
702		
703		
704		
705		
706		
707		
708		
709		
710		
711		
712		
713		
714		
715		
716		
717		
718		
719		
720		
721		
722		
723		
724		
725		
726		
727		
728		
729		
730		
731		
732		
733		
734		
735		
736		
737		
738		
739		
740		
741		
742		
743		
744		
745		
746		
747		
748		
749		
750		
751		
752		
753		
754		
755		
756		
757		
758		
759		
760		
761		
762		
763		
764		
765		
766		
767		
768		
769		
770		
771		
772		
773		
774		
775		
776		
777		
778		
779		
780		
781		
782		
783		
784		
785		
786		
787		
788		
789		
790		
791		
792		
793		
794		
795		
796		
797		
798		
799		
800		
801		
802		
803		
804		
805		
806		
807		
808		
809		
810		
811		
812		
813		
814		
815		
816		
817		
818		
819		
820		
821		
822		
823		
824		
825		
826		
827		
828		
829		
830		
831		
832		
833		
834		
835		
836		
837		
838		
839		
840		
841		
842		
843		
844		
845		
846		
847		
848		
849		
850		
851		
852		
853		
854		
855		
856		
857		
858		
859		
860		
861		
862		
863		
864		
865		
866		
867		
868		
869		
870		
871		
872		
873		
874		
875		
876		
877		
878		
879		
880		
881		
882		
883		
884		
885		
886		
887		
888		
889		
890		
891		
892		
893		
894		
895		
896		
897		
898		
899		
900		
901		
902		
903		
904		
905		
906		
907		
908		
909		
910		
911		
912		
913		
914		
915		
916		
917		

***APPENDIX C  
WIPE SAMPLING LABORATORY REPORT AND CHAIN  
OF CUSTODY DOCUMENTATION***



Experience is the solution

314 North Pearl Street • Albany, New York 12207 • 800-848-4983 • (518) 434-4546 • Fax (518) 434-0891

LABORATORY REPORT

for

SUNY-NEW PALTZ

\*\*ENGINEERING DEPARTMENT\*\*

\*\*\*\*\*

\*\*\*\*\* , \*\*\*\*\* \*\*\*\*

Attention: PETER BENTLEY

Purchase Order #: 970815EA

Report date: 08/21/97

Number of samples analyzed: 32

AES Project ID: 970818ED

Invoice #: 178962

ELAP ID#: 10709

AIHA ID#: 7866

Page

1

Albany

Syracuse

Rochester

Hartford, CT



Experience is the solution

314 North Pearl Street • Albany, New York 12207 • 800-848-4983 • (518) 434-4546 • Fax (518) 434-0891

CLIENT: SUNY-NEW PALTZ  
CLIENT'S SAMPLE ID: W1  
AES sample #: 970818ED01

Date Sampled: 08/18/97  
Date sample received: 08/19/97  
Samples taken by: Frisone/Watson Location: Suny New Paltz  
MATRIX: Wipe grab

<u>PARAMETER PERFORMED</u>	<u>METHOD</u>	<u>RESULT</u>	<u>UNITS</u>	<u>NOTEBK REF</u>	<u>TEST DATE</u>
PCB-1016	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1221	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1232	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1242	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1248	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1254	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1260	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97





Experience is the solution

314 North Pearl Street • Albany, New York 12207 • 800-848-4983 • (518) 434-4546 • Fax (518) 434-0891

CLIENT: SUNY-NEW PALTZ  
CLIENT'S SAMPLE ID: W2  
AES sample #: 970818EDO2

Date Sampled: 08/18/97  
Date sample received: 08/19/97  
Samples taken by: Frisone/Watson Location: Suny New Paltz  
MATRIX: Wipe grab

<u>PARAMETER PERFORMED</u>	<u>METHOD</u>	<u>RESULT</u>	<u>UNITS</u>	<u>NOTEBK REF</u>	<u>TEST DATE</u>
PCB-1016	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1221	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1232	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1242	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1248	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1254	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1260	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97



Experience is the solution

314 North Pearl Street • Albany, New York 12207 • 800-848-4983 • (518) 434-4546 • Fax (518) 434-0891

CLIENT: SUNY-NEW PALTZ  
CLIENT'S SAMPLE ID: W3  
AES sample #: 970818ED03

Date Sampled: 08/18/97  
Date sample received: 08/19/97  
Samples taken by: Frisone/Watson Location: Suny New Paltz  
MATRIX: Wipe grab

<u>PARAMETER PERFORMED</u>	<u>METHOD</u>	<u>RESULT</u>	<u>UNITS</u>	<u>NOTEBK REF</u>	<u>TEST DATE</u>
PCB-1016	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1221	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1232	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1242	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1248	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1254	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1260	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97



Experience is the solution

314 North Pearl Street • Albany, New York 12207 • 800-848-4983 • (518) 434-4546 • Fax (518) 434-0891

CLIENT: SUNY-NEW PALTZ  
CLIENT'S SAMPLE ID: W4  
AES sample #: 970818EDO4

Date Sampled: 08/18/97  
Date sample received: 08/19/97  
Samples taken by: Frisone/Watson Location: Suny New Paltz  
MATRIX: Wipe grab

<u>PARAMETER PERFORMED</u>	<u>METHOD</u>	<u>RESULT</u>	<u>UNITS</u>	<u>NOTEBK REF</u>	<u>TEST DATE</u>
PCB-1016	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1221	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1232	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1242	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1248	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1254	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1260	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97



Experience is the solution

314 North Pearl Street • Albany, New York 12207 • 800-848-4983 • (518) 434-4546 • Fax (518) 434-0891

CLIENT: SUNY-NEW PALTZ  
CLIENT'S SAMPLE ID: W5  
AES sample #: 970818ED05

Date Sampled: 08/18/97  
Date sample received: 08/19/97  
Samples taken by: Frisone/Watson Location: Suny New Paltz  
MATRIX: Wipe grab

<u>PARAMETER PERFORMED</u>	<u>METHOD</u>	<u>RESULT</u>	<u>UNITS</u>	<u>NOTEBK REF</u>	<u>TEST DATE</u>
PCB-1016	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1221	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1232	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1242	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1248	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1254	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1260	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97



Experience is the solution

314 North Pearl Street • Albany, New York 12207 • 800-848-4983 • (518) 434-4546 • Fax (518) 434-0891

CLIENT: SUNY-NEW PALTZ  
CLIENT'S SAMPLE ID: W6  
AES sample #: 970818ED06

Date Sampled: 08/18/97  
Date sample received: 08/19/97  
Samples taken by: Frisone/Watson Location: Suny New Paltz  
MATRIX: Wipe grab

<u>PARAMETER PERFORMED</u>	<u>METHOD</u>	<u>RESULT</u>	<u>UNITS</u>	<u>NOTEBK REF</u>	<u>TEST DATE</u>
PCB-1016	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1221	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1232	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1242	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1248	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1254	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1260	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97



Experience is the solution

314 North Pearl Street • Albany, New York 12207 • 800-848-4983 • (518) 434-4546 • Fax (518) 434-0891

CLIENT: SUNY-NEW PALTZ  
CLIENT'S SAMPLE ID: W7  
AES sample #: 970818ED07

Date Sampled: 08/18/97  
Date sample received: 08/19/97  
Samples taken by: Frisone/Watson Location: Suny New Paltz  
MATRIX: Wipe grab

<u>PARAMETER PERFORMED</u>	<u>METHOD</u>	<u>RESULT</u>	<u>UNITS</u>	<u>NOTEBK REF</u>	<u>TEST DATE</u>
PCB-1016	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1221	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1232	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1242	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1248	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1254	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1260	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97



Experience is the solution

314 North Pearl Street • Albany, New York 12207 • 800-848-4983 • (518) 434-4546 • Fax (518) 434-0891

CLIENT: SUNY-NEW PALTZ  
CLIENT'S SAMPLE ID: W8  
AES sample #: 970818EDO8

Date Sampled: 08/18/97

Date sample received: 08/19/97

Samples taken by: Frisone/Watson Location: Suny New Paltz  
MATRIX: Wipe grab

<u>PARAMETER PERFORMED</u>	<u>METHOD</u>	<u>RESULT</u>	<u>UNITS</u>	<u>NOTEBK REF</u>	<u>TEST DATE</u>
PCB-1016	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1221	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1232	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1242	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1248	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1254	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1260	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97



Experience is the solution

314 North Pearl Street • Albany, New York 12207 • 800-848-4983 • (518) 434-4546 • Fax (518) 434-0891

CLIENT: SUNY-NEW PALTZ  
CLIENT'S SAMPLE ID: W9  
AES sample #: 970818ED09

Date Sampled: 08/18/97  
Date sample received: 08/19/97  
Samples taken by: Frisone/Watson Location: Suny New Paltz  
MATRIX: Wipe grab

<u>PARAMETER PERFORMED</u>	<u>METHOD</u>	<u>RESULT</u>	<u>UNITS</u>	<u>NOTEBK REF</u>	<u>TEST DATE</u>
PCB-1016	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1221	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1232	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1242	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1248	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1254	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1260	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97





Experience is the solution

314 North Pearl Street • Albany, New York 12207 • 800-848-4983 • (518) 434-4546 • Fax (518) 434-0891

CLIENT: SUNY-NEW PALTZ  
CLIENT'S SAMPLE ID: W10  
AES sample #: 970818ED10

Date Sampled: 08/18/97  
Date sample received: 08/19/97  
Samples taken by: Frisone/Watson Location: Suny New Paltz  
MATRIX: Wipe grab

<u>PARAMETER PERFORMED</u>	<u>METHOD</u>	<u>RESULT</u>	<u>UNITS</u>	<u>NOTEBOOK REF</u>	<u>TEST DATE</u>
PCB-1016	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1221	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1232	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1242	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1248	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1254	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1260	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97



Experience is the solution

314 North Pearl Street • Albany, New York 12207 • 800-848-4983 • (518) 434-4546 • Fax (518) 434-0891

CLIENT: SUNY-NEW PALTZ  
CLIENT'S SAMPLE ID: W11  
AES sample #: 970818ED11

Date Sampled: 08/18/97  
Date sample received: 08/19/97  
Samples taken by: Frisone/Watson Location: Suny New Paltz  
MATRIX: Wipe grab

<u>PARAMETER PERFORMED</u>	<u>METHOD</u>	<u>RESULT</u>	<u>UNITS</u>	<u>NOTEBK REF</u>	<u>TEST DATE</u>
PCB-1016	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1221	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1232	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1242	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1248	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1254	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1260	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97



Experience is the solution

314 North Pearl Street • Albany, New York 12207 • 800-848-4983 • (518) 434-4546 • Fax (518) 434-0891

CLIENT: SUNY-NEW PALTZ  
CLIENT'S SAMPLE ID: W12  
AES sample #: 970818ED12

Date Sampled: 08/18/97  
Date sample received: 08/19/97  
Samples taken by: Frisone/Watson Location: Suny New Paltz  
MATRIX: Wipe grab

<u>PARAMETER PERFORMED</u>	<u>METHOD</u>	<u>RESULT</u>	<u>UNITS</u>	<u>NOTEBOOK REF</u>	<u>TEST DATE</u>
PCB-1016	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1221	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1232	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1242	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1248	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1254	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1260	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97



Experience is the solution

314 North Pearl Street • Albany, New York 12207 • 800-848-4983 • (518) 434-4546 • Fax (518) 434-0891

CLIENT: SUNY-NEW PALTZ  
CLIENT'S SAMPLE ID: W13  
AES sample #: 970818ED13

Date Sampled: 08/18/97

Date sample received: 08/19/97

Samples taken by: Frisone/Watson Location: Suny New Paltz  
MATRIX: Wipe grab

<u>PARAMETER PERFORMED</u>	<u>METHOD</u>	<u>RESULT</u>	<u>UNITS</u>	<u>NOTEBOOK REF</u>	<u>TEST DATE</u>
PCB-1016	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1221	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1232	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1242	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1248	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1254	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1260	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97



Experience is the solution

314 North Pearl Street • Albany, New York 12207 • 800-848-4983 • (518) 434-4546 • Fax (518) 434-0891

CLIENT: SUNY-NEW PALTZ  
CLIENT'S SAMPLE ID: W14  
AES sample #: 970818ED14

Date Sampled: 08/18/97

Date sample received: 08/19/97

Samples taken by: Frisone/Watson Location: Suny New Paltz  
MATRIX: Wipe grab

<u>PARAMETER PERFORMED</u>	<u>METHOD</u>	<u>RESULT</u>	<u>UNITS</u>	<u>NOTEBK REF</u>	<u>TEST DATE</u>
PCB-1016	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1221	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1232	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1242	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1248	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1254	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1260	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97



Experience is the solution

314 North Pearl Street • Albany, New York 12207 • 800-848-4983 • (518) 434-4546 • Fax (518) 434-0891

CLIENT: SUNY-NEW PALTZ  
CLIENT'S SAMPLE ID: W15  
AES sample #: 970818ED15

Date Sampled: 08/18/97  
Date sample received: 08/19/97  
Samples taken by: Frisone/Watson Location: Suny New Paltz  
MATRIX: Wipe grab

<u>PARAMETER PERFORMED</u>	<u>METHOD</u>	<u>RESULT</u>	<u>UNITS</u>	<u>NOTEBK REF</u>	<u>TEST DATE</u>
PCB-1016	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1221	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1232	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1242	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1248	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1254	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1260	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97



Experience is the solution

314 North Pearl Street • Albany, New York 12207 • 800-848-4983 • (518) 434-4546 • Fax (518) 434-0891

CLIENT: SUNY-NEW PALTZ  
CLIENT'S SAMPLE ID: W16  
AES sample #: 970818ED16

Date Sampled: 08/18/97

Date sample received: 08/19/97

Samples taken by: Frisone/Watson Location: Suny New Paltz  
MATRIX: Wipe grab

<u>PARAMETER PERFORMED</u>	<u>METHOD</u>	<u>RESULT</u>	<u>UNITS</u>	<u>NOTEBK REF</u>	<u>TEST DATE</u>
PCB-1016	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1221	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1232	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1242	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1248	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1254	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1260	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97



Experience is the solution

314 North Pearl Street • Albany, New York 12207 • 800-848-4983 • (518) 434-4546 • Fax (518) 434-0891

CLIENT: SUNY-NEW PALTZ  
CLIENT'S SAMPLE ID: W17  
AES sample #: 970818ED17

Date Sampled: 08/18/97  
Date sample received: 08/19/97  
Samples taken by: Frisone/Watson Location: Suny New Paltz  
MATRIX: Wipe grab

<u>PARAMETER PERFORMED</u>	<u>METHOD</u>	<u>RESULT</u>	<u>UNITS</u>	<u>NOTE/CK REF</u>	<u>TEST DATE</u>
PCB-1016	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1221	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1232	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1242	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1248	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1254	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1260	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97





Experience is the solution

314 North Pearl Street • Albany, New York 12207 • 800-848-4983 • (518) 434-4546 • Fax (518) 434-0891

CLIENT: SUNY-NEW PALTZ  
CLIENT'S SAMPLE ID: W18  
AES sample #: 970818ED18

Date Sampled: 08/18/97  
Date sample received: 08/19/97  
Samples taken by: Frisone/Watson Location: Suny New Palitz  
MATRIX: Wipe grab

<u>PARAMETER PERFORMED</u>	<u>METHOD</u>	<u>RESULT</u>	<u>UNITS</u>	<u>NOTEBK REF</u>	<u>TEST DATE</u>
PCB-1016	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1221	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1232	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1242	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1248	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1254	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1260	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97



Experience is the solution

314 North Pearl Street • Albany, New York 12207 • 800-848-4983 • (518) 434-4546 • Fax (518) 434-0891

CLIENT: SUNY-NEW PALTZ  
CLIENT'S SAMPLE ID: W19  
AES sample #: 970818ED19

Date Sampled: 08/18/97  
Date sample received: 08/19/97  
Samples taken by: Frisone/Watson Location: Suny New Paltz  
MATRIX: Wipe grab

<u>PARAMETER PERFORMED</u>	<u>METHOD</u>	<u>RESULT</u>	<u>UNITS</u>	<u>NOTEBK REF</u>	<u>TEST DATE</u>
PCB-1016	EPA-8030	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1221	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1232	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1242	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1248	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1254	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1260	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97



Experience is the solution

314 North Pearl Street • Albany, New York 12207 • 800-848-4983 • (518) 434-4546 • Fax (518) 434-0891

CLIENT: SUNY-NEW PALTZ  
CLIENT'S SAMPLE ID: W20  
AES sample #: 970818ED20

Date Sampled: 08/18/97  
Date sample received: 08/19/97  
Samples taken by: Frisone/Watson Location: Suny New Paltz  
MATRIX: Wipe grab

<u>PARAMETER PERFORMED</u>	<u>METHOD</u>	<u>RESULT</u>	<u>UNITS</u>	<u>NOTEBK REF</u>	<u>TEST DATE</u>
PCB-1016	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1221	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1232	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1242	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1248	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1254	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1260	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97



Experience is the solution

314 North Pearl Street • Albany, New York 12207 • 800-848-4983 • (518) 434-4546 • Fax (518) 434-0891

CLIENT: SUNY-NEW PALTZ  
CLIENT'S SAMPLE ID: W21  
AES sample #: 970818ED21

Date Sampled: 08/18/97  
Date sample received: 08/19/97  
Samples taken by: Frisone/Watson Location: Suny New Paltz  
MATRIX: Wipe grab

<u>PARAMETER PERFORMED</u>	<u>METHOD</u>	<u>RESULT</u>	<u>UNITS</u>	<u>NOTEBK REF</u>	<u>TEST DATE</u>
PCB-1016	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1221	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1232	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1242	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1248	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1254	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1260	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97



Experience is the solution

314 North Pearl Street • Albany, New York 12207 • 800-848-4983 • (518) 434-4546 • Fax (518) 434-0891

CLIENT: SUNY-NEW PALTZ  
CLIENT'S SAMPLE ID: W22  
AES sample #: 970818ED22

Date Sampled: 08/18/97  
Date sample received: 08/19/97

Samples taken by: Frisone/Watson Location: Suny New Paltz  
MATRIX: Wipe grab

<u>PARAMETER PERFORMED</u>	<u>METHOD</u>	<u>RESULT</u>	<u>UNITS</u>	<u>NOTEBK REF</u>	<u>TEST DATE</u>
PCB-1016	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1221	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1232	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1242	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1248	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1254	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1260	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97



Experience is the solution

314 North Pearl Street • Albany, New York 12207 • 800-848-4983 • (518) 434-4546 • Fax (518) 434-0891

CLIENT: SUNY-NEW PALTZ  
CLIENT'S SAMPLE ID: W23  
AES sample #: 970818ED23

Date Sampled: 08/18/97  
Date sample received: 08/19/97  
Samples taken by: Frisone/Watson Location: Suny New Paltz  
MATRIX: Wipe grab

<u>PARAMETER PERFORMED</u>	<u>METHOD</u>	<u>RESULT</u>	<u>UNITS</u>	<u>NOTEBK REF</u>	<u>TEST DATE</u>
PCB-1016	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1221	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1232	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1242	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1248	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1254	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1260	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97



Experience is the solution

314 North Pearl Street • Albany, New York 12207 • 800-848-4983 • (518) 434-4546 • Fax (518) 434-0891

CLIENT: SUNY-NEW PALTZ  
CLIENT'S SAMPLE ID: W24  
AES sample #: 970818ED24

Date Sampled: 03/18/97  
Date sample received: 03/19/97  
Samples taken by: Frisone/Watson Location: Suny New Paltz  
MATRIX: Wipe grab

<u>PARAMETER PERFORMED</u>	<u>METHOD</u>	<u>RESULT</u>	<u>UNITS</u>	<u>NOTEBOOK REF</u>	<u>TEST DATE</u>
PCB-1016	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1221	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1232	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1242	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1248	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1254	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1260	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97



Experience is the solution

314 North Pearl Street • Albany, New York 12207 • 800-848-4983 • (518) 434-4546 • Fax (518) 434-0891

CLIENT: SUNY-NEW PALTZ  
CLIENT'S SAMPLE ID: W25  
AES sample #: 970818ED25

Date Sampled: 08/18/97  
Date sample received: 08/19/97  
Samples taken by: Frisone/Watson Location: Suny New Paltz  
MATRIX: Wipe grab

<u>PARAMETER PERFORMED</u>	<u>METHOD</u>	<u>RESULT</u>	<u>UNITS</u>	<u>NOTEBK REF</u>	<u>TEST DATE</u>
PCB-1016	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1221	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1232	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1242	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1248	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1254	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1260	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97





Experience is the solution

314 North Pearl Street • Albany, New York 12207 • 800-848-4983 • (518) 434-4546 • Fax (518) 434-0891

CLIENT: SUNY-NEW PALTZ  
CLIENT'S SAMPLE ID: W26  
AES sample #: 970818ED26

Date Sampled: 08/18/97

Date sample received: 08/19/97

Samples taken by: Frisone/Watson Location: Suny New Paltz  
MATRIX: Wipe grab

<u>PARAMETER PERFORMED</u>	<u>METHOD</u>	<u>RESULT</u>	<u>UNITS</u>	<u>NOTEBK REF</u>	<u>TEST DATE</u>
PCB-1016	EPA-3080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1221	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1232	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1242	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1248	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1254	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1260	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97



Experience is the solution

314 North Pearl Street • Albany, New York 12207 • 800-848-4983 • (518) 434-4546 • Fax (518) 434-0891

CLIENT: SUNY-NEW PALTZ  
CLIENT'S SAMPLE ID: W27  
AES sample #: 970818ED27

Date Sampled: 08/18/97  
Date sample received: 08/19/97  
Samples taken by: Frisone/Watson Location: Suny New Paltz  
MATRIX: Wipe grab

<u>PARAMETER PERFORMED</u>	<u>METHOD</u>	<u>RESULT</u>	<u>UNITS</u>	<u>NOTEBK REF</u>	<u>TEST DATE</u>
PCB-1016	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1221	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1232	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1242	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1248	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1254	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1260	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97



Experience is the solution

314 North Pearl Street • Albany, New York 12207 • 800-848-4983 • (518) 434-4546 • Fax (518) 434-0891

CLIENT: SUNY-NEW PALTZ  
CLIENT'S SAMPLE ID: W28  
AES sample #: 970818ED28

Date Sampled: 08/18/97

Date sample received: 08/19/97

Samples taken by: Frisone/Watson Location: Suny New Paltz  
MATRIX: Wipe grab

<u>PARAMETER PERFORMED</u>	<u>METHOD</u>	<u>RESULT</u>	<u>UNITS</u>	<u>NOTEBK REF</u>	<u>TEST DATE</u>
PCB-1016	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1221	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1232	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1242	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1248	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1254	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1260	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97



Experience is the solution

314 North Pearl Street • Albany, New York 12207 • 800-848-4983 • (518) 434-4546 • Fax (518) 434-0891

CLIENT: SUNY-NEW PALTZ  
CLIENT'S SAMPLE ID: W29  
AES sample #: 970818ED29

Date Sampled: 08/18/97

Date sample received: 08/19/97

Samples taken by: Frisone/Watson Location: Suny New Paltz  
MATRIX: Wipe grab

<u>PARAMETER PERFORMED</u>	<u>METHOD</u>	<u>RESULT</u>	<u>UNITS</u>	<u>NOTEBOOK REF</u>	<u>TEST DATE</u>
PCB-1016	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1221	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1232	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1242	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1248	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1254	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1260	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97



Experience is the solution

314 North Pearl Street • Albany, New York 12207 • 800-848-4983 • (518) 434-4546 • Fax (518) 434-0891

CLIENT: SUNY-NEW PALTZ  
CLIENT'S SAMPLE ID: W30  
AES sample #: 970818ED30

Date Sampled: 08/18/97  
Date sample received: 08/19/97  
Samples taken by: Frisone/Watson Location: Suny New Paltz  
MATRIX: Wipe grab

<u>PARAMETER PERFORMED</u>	<u>METHOD</u>	<u>RESULT</u>	<u>UNITS</u>	<u>NOTEBK REF</u>	<u>TEST DATE</u>
PCB-1016	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1221	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1232	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1242	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1248	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1254	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1260	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97



Experience is the solution

314 North Pearl Street • Albany, New York 12207 • 800-848-4983 • (518) 434-4546 • Fax (518) 434-0891

CLIENT: SUNY-NEW PALTZ  
CLIENT'S SAMPLE ID: W31  
AES sample #: 970818ED31

Date Sampled: 08/18/97

Date sample received: 08/19/97

Samples taken by: Frisone/Watson Location: Suny New Paltz  
MATRIX: Wipe grab

<u>PARAMETER PERFORMED</u>	<u>METHOD</u>	<u>RESULT</u>	<u>UNITS</u>	<u>NOTEBK REF</u>	<u>TEST DATE</u>
PCB-1016	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1221	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1232	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1242	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1248	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1254	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1260	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97



Experience is the solution

314 North Pearl Street • Albany, New York 12207 • 800-848-4983 • (518) 434-4546 • Fax (518) 434-0891

CLIENT: SUNY-NEW PALTZ  
CLIENT'S SAMPLE ID: W32  
AES sample #: 970818ED32

Date Sampled: 08/18/97

Date sample received: 08/19/97

Samples taken by: Frisone/Watson Location: Suny New Paltz  
MATRIX: Wipe grab

<u>PARAMETER PERFORMED</u>	<u>METHOD</u>	<u>RESULT</u>	<u>UNITS</u>	<u>NOTE/REF</u>	<u>TEST DATE</u>
PCB-1016	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1221	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1232	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1242	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1248	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1254	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97
PCB-1260	EPA-8080	<1 ug/	900cm2	KF-PCB-W-7	08/19/97

APPROVED BY:   
Report date: 08/21/97



314 North Pearl Street  
Albany, New York 12207  
518-434-4546/434-0891 FAX

REQUEST FOR ANALYSIS

CLIENT NAME <b>S.U.N.Y.-NEW PALTZ</b>	PROJECT NAME (Location) <b>Sunny Hill, Pk 2 Pk B</b>	SAMPLERS' (Names) <b>J. FRISONO/P. WATSON</b>
ADDRESS	PO NUMBER <b>970 815EA</b>	SAMPLERS' (Signatures) <i>[Signatures]</i>

970818

AES SAMPLE NUMBER	SAMPLE IDENTIFICATION	DATE SAMPLED	TIME A = A.M. P = P.M.	MEDIA TYPE/ MATRIX	NO. OF CONT'S	AIR SAMPLE VOLUME (LITERS)	TOTAL SAMPLING TIME (MIN.)	ANALYSIS REQUESTED
ED01	W1	8/18/97	8:33 A	W.P.C.	1			EPA 8080 - PL
ED02	W2		8:35 A					
ED03	W3		9:42 A					
ED04	W4		9:42 A					
ED05	W5		9:50 A					
ED06	W6		10:00 A					
ED07	W7		10:00 A					
ED08	W8		10:25 A					
ED09	W9		11:41 A					
ED10	W10		10:40 A					
ED11	W11		10:50 A					
ED12	W12		10:50 A					
ED13	W13		11:05 A					
ED14	W14		11:00 A					

SEND REPORT TO <b>PAUL WATSON</b>	SEND INVOICE TO <b>PAUL WATSON</b>	COMMENTS
--------------------------------------	---------------------------------------	----------

TURN-AROUND TIME — PLEASE CHECK ALL THAT APPLY

\*STANDARD SERVICE

\*RUSH SERVICE — Results requested by **5 DAYS**

FAX RESULTS TO: **PETER BETLEY** FAX # **914 257-3338**

PHONE RESULTS TO: \_\_\_\_\_ PH # ( ) \_\_\_\_\_

\*Turn-around time varies by substance. For most substances, standard turn-around time is ten (10) working days.  
Please inquire for capacity of rush analysis.

LABORATORY APPROVAL	DATE	TIME	RECEIVED FOR LABORATORY BY <b>M. LP</b>	DATE <b>8/19/97</b>	TIME <b>7:30</b>
---------------------	------	------	--	------------------------	---------------------

CHAIN OF CUSTODY

RELINQUISHED BY (Signature) <i>[Signature]</i>	RECEIVED BY (Signature)	DATE	TIME
RELINQUISHED BY (Signature)	RECEIVED BY (Signature)	DATE	TIME





314 North Pearl Street  
Albany, New York 12207  
518-434-4546 / 434-0891 FAX

REQUEST FOR ANALYSIS

CLIENT NAME <b>SUNY - NEW PALTZ</b>	PROJECT NAME (Location) <b>SUNY NEW PALTZ-PCB</b>	SAMPLERS' (Names) <b>J. FRISONE / P. WATSON</b>
ADDRESS	PO NUMBER <b>970815EA</b>	SAMPLERS' (Signatures) <i>[Signatures]</i>

AES SAMPLE NUMBER	SAMPLE IDENTIFICATION	DATE SAMPLED	TIME A = A.M. P = P.M.	MEDIA TYPE/ MATRIX	NO. OF CONT'S	AIR SAMPLE VOLUME (LITERS)	TOTAL SAMPLING TIME (MIN.)	ANALYSIS REQUESTED
970818 ED15	W15	8/18/97	11:50 A	WIPE	1			EPA 8080-PC
ED16	W16		11:50 A					
ED17	W17		11:32 A					
ED18	W18		11:35 A					
ED19	W19		11:40 A					
ED20	W20		11:43 A					
ED21	W21		2:32 P					
ED22	W22		2:43 P					
ED23	W23		2:52 P					
ED24	W24		2:56 P					
ED25	W25		3:01 P					
ED26	W26		3:05 P					
ED27	W27		3:08 P					
ED28	W28		3:24 P					

SEND REPORT TO <b>PAUL WATSON</b>	SEND INVOICE TO <b>PAUL WATSON</b>	COMMENTS
--------------------------------------	---------------------------------------	----------

TURN-AROUND TIME - PLEASE CHECK ALL THAT APPLY

\*STANDARD SERVICE

\*RUSH SERVICE - Results requested by: **5 DAYS**

FAX RESULTS TO: **PETE BETLEY** FAX # **(914) 257-3388**

PHONE RESULTS TO: PH # ( )


\*Turn-around time varies by substance. For most substances, standard turn-around time is ten (10) working days. Please inquire for capacity of rush analysis.

LABORATORY APPROVAL	DATE	TIME	RECEIVED FOR LABORATORY BY <b>M. LP</b>	DATE <b>8/19/97</b>	TIME <b>7:30</b>
---------------------	------	------	--	------------------------	---------------------

CHAIN OF CUSTODY

RELINQUISHED BY (Signature) <i>[Signature]</i>	RECEIVED BY (Signature)	DATE	TIME
RELINQUISHED BY (Signature)	RECEIVED BY (Signature)	DATE	TIME





STOP

17.858

RUN# 13326      AUG 19, 1997 07:47:46

SAMPLE NAME: 1242 0.5      SAMPLE# 1  
2

AREA%


RT	AREA	TYPE	WIDTH	AREA%
.748	78115	PV	.040	6.51715
.877	3623	VB	.045	.30227
1.855	129	BB	.039	.01076
1.500	251	PB	.697	.02094
1.626	722	BB	.051	.06024
1.770	719	BB	.075	.05999
2.000	61	BB	.038	.00509
2.340	7029	PB	.008	.58643
2.657	3941	BB	.062	.32880
2.866	49854	BB	.112	4.15933
3.145	5201	BB	.089	.44059
3.540	80763	BB	.123	6.73807
3.842	42011	BB	.105	3.57173
4.377	90103	BB	.115	7.51731
4.575	45808	BB	.178	3.82177
5.213	76417	BB	.244	6.37548
5.558	42507	BB	.143	3.54637
5.804	37090	BB	.140	3.09509
6.510	102766	PB	.226	8.57379
6.915	26246	BB	.149	2.18971
7.198	4446	BB	.174	.37093
7.798	6856	PB	.177	.57200
8.034	6694	BB	.123	.55848
8.752	13556	VB	.210	1.13098
9.350	9340	BB	.191	.77924
9.850	882	PB	.127	.07359
10.046	1237	BB	.134	.10320
10.661	136	PB	.087	.01135
14.615	138	BB	.460	.01151
16.268	461051	BB	.210	38.46558
17.858	27	PB	.056	.00225

*PCB W7*

TOTAL AREA=1198607  
MUL FACTOR=1.0000E+00

RUN #13327  
START

AUG 19, 1997 08:09:36



STOP

RUN# 13327

AUG 19, 1997 08:09:36

SAMPLE NAME: 1254 0.5

SAMPLE# 2

AREAX


RT	AREA	TYPE	WIDTH	AREAX
.736	38716	PB	.033	2.59745
.865	228	BP	.010	.01530
1.601	767	VB	.054	.05146
1.974	3080	BB	.088	.20664
2.837	872	VB	.105	.05850
3.510	1842	PB	.118	.12358
3.812	900	BB	.106	.06038
4.343	2453	PB	.112	.16457
4.555	1559	BB	.129	.10459
5.095	73570	PB	.177	4.93580
5.585	26012	BB	.134	1.74514
5.775	6406	BB	.119	.42978
6.540	152407	BB	.219	10.22495
7.181	176131	BB	.276	11.81659
7.763	35875	BB	.152	2.40685
8.011	74975	BB	.145	5.03005
8.721	142921	BB	.230	9.58854
9.359	110643	BB	.209	7.42301
9.684	3223	BB	.101	.21623
10.040	113226	BB	.214	7.59631
10.645	27551	BB	.205	1.84839
11.163	511	BB	.101	.03428
11.370	9647	BB	.190	.64722
11.925	10608	BB	.189	.71169
12.595	11506	PB	.217	.77194
13.897	210	BB	.151	.01463
14.684	427	PB	2.372	.02865
16.243	464222	BB	.213	31.14454
17.620	44	PB	.244	.00295

TOTAL AREA=1490540  
MUL FACTOR=1.0000E+00

10690

RUN #13334  
START

AUG 19, 1997 11:16:39



STOP

RUN# 13334

AUG 19, 1997 11:16:39

SAMPLE NAME: 818ED1  
2

SAMPLE# 1


AREA%

RT	AREA	TYPE	WIDTH	AREA%
.728	52132	PB	.040	13.80450
1.150	480	PB	.050	.12710
1.480	257	PB	.056	.06805
1.595	454	BB	.051	.12022
1.770	220	PB	.052	.05826
2.042	2656	BB	.094	.70331
3.382	260	PB	.003	.06885
4.199	752	PB	.117	.19913
5.197	1645	PB	.147	.43559
5.733	44269	PB	.134	11.72238
7.100	185	PB	.193	.04899
8.270	66	PB	.550	.01748
9.795	23672	PB	.224	6.26832
13.511	527	PB	2.928	.13955
13.905	1430	PB	.168	.37866
16.233	248460	PB	.228	65.79197
17.381	103	PB	.429	.02727
17.649	40	VB	.222	.01059
17.930	37	PB	.206	.00980

TOTAL AREA= 377645  
MUL FACTOR=1.0000E+00

RUN #13335  
START

AUG 19, 1997 11:38:27



STOP

RUN# 13335

AUG 19, 1997 11:38:27

SAMPLE NAME: 818ED2

SAMPLE# 2

AREA%


RT	AREA	TYPE	WIDTH	AREA%
.729	64158	PB	.036	16.01712
1.146	426	PB	.044	.10635
1.476	345	PB	.061	.08613
2.033	819	VB	.104	.20446
3.615	613	BB	.129	.15304
4.191	710	PB	.130	.17725
5.195	2219	PB	.153	.55398
5.728	881	I PB	.124	.21994
9.795	16279	PB	.217	4.06407
12.397	335	PB	1.396	.08363
13.922	716	PB	.628	.17875
14.235	257	PB	.428	.06416
15.482	276	PB	.460	.06890
16.229	312479	BB	.220	78.01072
17.718	46	BB	.192	.01148

TOTAL AREA= 400559

MUL FACTOR=1.0000E+00

RUN #13336  
START

AUG 19, 1997 12:00:31



STOP

RUN# 13336

AUG 19, 1997 12:00:31

SAMPLE NAME: 818ED3

SAMPLE# 3

4

AREA%


RT	AREA	TYPE	WIDTH	AREA%
.734	32979	PV	.056	9.00893
.975	1640	VB	.077	.44800
1.146	647	BB	.043	.17674
1.477	722	PB	.087	.19723
2.030	1087	PB	.096	.29694
3.371	319	PB	.087	.08714
5.725	46595	PB	.133	12.72844
6.517	287	PB	.126	.07840
7.045	127	PB	.068	.03469
8.538	16	PB	.089	.00437
8.682	979	BB	.147	.26744
9.361	2214	PB	.215	.60480
9.795	19895	BB	.258	5.43475
10.560	13	PB	.043	.00355
11.508	72	PB	.240	.01967
11.742	3586	BB	.249	.97959
13.905	109	BB	.908	.02978
14.190	270	PB	.409	.07376
16.228	254190	PB	.218	69.43754
17.820	323	BB	1.346	.08023

TOTAL AREA= 366070

MUL FACTOR=1.0000E+00

RUN #13337  
START

AUG 19, 1997 12:22:18



STOP

RUN# 13337

AUG 19, 1997 12:22:18

SAMPLE NAME: 818ED4  
725LBLK

SAMPLE# 4

AREA%

RT	AREA	TYPE	WIDTH	AREA%
.735	36548	PB	.058	8.31714
.988	601	BB	.043	.13677
1.147	861	PB	.037	.19594
1.478	699	PB	.064	.15907
1.770	552	PB	.069	.12562
2.034	603	BB	.091	.13722
2.842	420	BB	.076	.09558
3.381	870	BB	.093	.19798
4.169	958	PB	.143	.21801
5.731	118194	PB	.130	26.89713
7.145	633	PB	.251	.14405
9.371	1113	PB	.199	.25328
9.796	16311	PB	.239	3.71185
11.525	54	PB	.129	.01229
12.358	104	PB	.433	.02367
12.670	54	BB	.225	.01229
14.275	122	PB	.678	.02776
16.220	260673	BB	.195	59.32070
17.865	60	PB	.250	.01365


TOTAL AREA= 439430

MUL FACTOR=1.00000E+00



RUN #13338  
START

AUG 19, 1997 12:44:12



STOP

RUN# 13338

AUG 19, 1997 12:44:12

SAMPLE NAME: 818ED5

SAMPLE# 5

AREA%

RT	AREA	TYPE	WIDTH	AREA%
.732	47961	PB	.048	10.15699
.976	731	BB	.057	.15481
1.149	1266	BB	.039	.26811
1.478	1159	PB	.073	.24545
1.773	302	PB	.064	.06396
2.037	818	I VB	.097	.17323
2.846	424	BB	.080	.08979
3.384	426	PB	.083	.09022
4.174	2265	BB	.135	.47967
4.688	717	PB	.124	.15184
5.078	407	PB	.092	.08619
5.492	166	BB	.084	.03515
5.737	67999	BB	.130	14.40056
6.523	3696	PB	.188	.78272
7.166	6350	BB	.279	1.34478
7.991	2315	BB	.151	.49026
8.697	4180	PB	.195	.88522
9.356	4182	PB	.211	.88565
9.797	21445	BB	.254	4.54154
10.614	349	PB	.135	.07391
11.404	127	BB	2.117	.02690
11.742	9802	BB	.230	2.07583
12.669	199	PB	.663	.04214
14.800	11187	PB	.220	2.36914
15.422	36	PB	.120	.00762
16.230	283688	PB	.215	60.07830


$$\frac{20723}{45537} \times 0.025 \times 20 = 0.2 \text{ ugs/wipe}$$

TOTAL AREA= 472197  
MUL FACTOR=1.0000E+00

RUN #13339

AUG 19, 1997 13:06:00

START



STOP

RUN# 13339

AUG 19, 1997 13:06:00

SAMPLE NAME: 818ED6  
5

SAMPLE# 6

AREAX


RT	AREA	TYPE	WIDTH	AREA%
.732	34562	PB	.055	7.42710
.981	1063	BB	.045	.22843
1.145	965	BB	.040	.20737
1.475	697	PB	.059	.14978
2.030	1362	PB	.078	.29268
4.170	1906	I PB	.135	.40958
4.648	29	PB	.044	.00623
5.724	40553	VB	.133	8.71452
6.509	2715	PB	.185	.58343
7.150	5015	PB	.268	1.07768
7.738	881	PB	.136	.18932
7.987	2273	BB	.140	.48845
8.688	4242	VB	.195	.91157
9.338	4194	PB	.213	.90126
9.791	20754	BB	.292	4.45987
11.739	6795	PB	.222	1.46019
12.608	615	I PB	.123	.13216
13.395	22	PB	.122	.00473
13.633	15	BB	.083	.00322
13.880	43	BB	.072	.00924
14.160	563	PB	.168	.12098
14.804	2040	PB	.141	.43838
15.428	385	PB	.120	.08273
16.222	333580	PB	.208	71.68541
17.309	73	PB	.243	.01569

TOTAL AREA= 465350

$$\frac{19320}{45537} \times 0.025 \times 20 = 0.2 \text{ ugS/wipe}$$

RUN #13340  
START

AUG 19, 1997 13:27:50



STOP

RUN# 13340

AUG 19, 1997 13:27:50

SAMPLE NAME: 818E07

SAMPLE# 7

AREA%


RT	AREA	TYPE	WIDTH	AREA%
.734	31710	PB	.058	6.19086
.977	319	BB	.053	.06228
1.090	209	BB	.026	.04080
1.149	318	BB	.039	.06208
1.480	497	PB	.067	.09703
1.774	564	PB	.063	.11011
2.845	536	PB	.080	.10465
3.377	1012	PB	.092	.19758
4.158	1948	PB	.127	.38031
5.716	158968	PB	.128	31.03589
6.510	464	PB	.143	.09059
9.793	28452	PB	.236	5.55478
11.443	68	PB	.227	.01328
13.944	573	BB	.503	.11187
15.496	404	BB	.962	.07887
16.239	286130	BB	.212	55.86218
17.548	35	BB	.194	.00683

TOTAL AREA= 512207

MUL FACTOR=1.0000E+00

RUN #13341  
START

AUG 19, 1997 13:49:36



STOP

17.953

RUN# 13341

AUG 19, 1997 13:49:36

SAMPLE NAME: 818ED8

SAMPLE# 8

AREA%


RT	AREA	TYPE	WIDTH	AREA%
.733	34301	PV	.060	6.27239
1.157	608	VB	.067	.11118
1.290	240	BB	.046	.04389
1.480	234	BB	.053	.04279
1.593	825	BB	.053	.15086
1.770	371	BB	.061	.06784
2.035	2405	BB	.101	.43979
3.381	639	PB	.089	.11685
4.176	642	PB	.135	.11740
5.185	879	VB	.163	.16074
5.729	100892	PB	.129	18.44943
7.040	106	PB	.088	.01938
7.756	78	PB	.130	.01426
8.685	936	VB	.175	.17116
9.793	28677	PB	.241	5.24397
11.558	99	PB	.413	.01810
12.705	147	PB	1.225	.02688
13.410	25	PB	.139	.00457
14.240	65	PB	.271	.01189
16.226	374502	PB	.214	68.48262
17.953	186	PB	.620	.03401

TOTAL AREA= 546857

MUL FACTOR=1.0000E+00

RUN #13342  
START

AUG 19, 1997 14:11:24



STOP

RUN# 13342

AUG 19, 1997 14:11:24

SAMPLE NAME: 818E09

SAMPLE# 9

AREA%


RT	AREA	TYPE	WIDTH	AREA%
.731	35975	PB	.059	5.83305
.978	312	BB	.042	.05059
1.146	454	BB	.042	.07361
1.290	280	BB	.055	.04540
1.478	205	BB	.044	.03324
1.591	505	BB	.046	.08188
1.771	621	BB	.061	.10069
2.035	1417	BB	.105	.22976
2.841	634	PB	.079	.10280
3.380	1229	BB	.089	.19927
4.170	796	VB	.126	.12906
4.699	563	PB	.141	.09210
5.728	174861	PB	.127	28.35228
7.019	71	PB	.091	.01151
9.782	23802	BB	.212	3.85930
13.890	250	PB	.076	.04054
16.235	374764	PB	.205	60.76493

TOTAL AREA= 616744

MUL FACTOR=1.0000E+00

RUN #13343  
START

AUG 19, 1997 14:33:11



STOP

RUN# 13343

AUG 19, 1997 14:33:11

SAMPLE NAME: 818ED10

SAMPLE# 10

6

AREAX


RT	AREA	TYPE	WIDTH	AREAX
.737	31498	PB	.060	7.79499
1.480	587	PB	.088	.14527
2.038	1257	PB	.098	.31108
5.185	761	VB	.159	.18833
5.733	22472	I PB	.136	5.56128
7.048	87	PB	.104	.02153
8.695	37	PB	.206	.00916
9.800	18264	PB	.222	4.51990
12.745	106	BB	.353	.02623
15.454	240	BB	.667	.05939
16.234	328656	PB	.223	81.33437
17.616	66	BB	.220	.01633
17.859	49	BB	.163	.01213

TOTAL AREA= 404080

MUL FACTOR=1.0000E+00

RUN #13344  
START

AUG 19, 1997 14:55:01



STOP

RUN# 13344

AUG 19, 1997 14:55:01

SAMPLE NAME: 1254 0.025

SAMPLE# 11

AREA%

RT	AREA	TYPE	WIDTH	AREA%
.732	61599	PV	.033	36.42842
.860	4512	VV	.066	2.66831
1.596	1498	VB	.064	.88589
2.040	5091	PB	.111	3.01072
4.190	396	PB	.096	.23419
4.660	74	PB	.077	.04376
5.086	5719	BB	.210	3.38210
5.493	887	BB	.106	.52455
5.735	12678	BB	.135	7.49752
6.523	9805	PB	.208	5.79848
7.165	12149	PB	.267	7.18468
7.746	2156	PB	.150	1.27502
7.993	4837	BB	.149	2.86051
8.706	9434	PB	.227	5.57908
9.344	7146	PB	.207	4.22600
9.813	40	BB	.048	.02366
10.019	5472	BB	.192	3.23603
10.640	1126	PB	.174	.66589
11.498	144	PB	.080	.08516
16.205	24333	BB	.153	14.39005

45537

All

51049

TOTAL AREA= 169096  
MUL FACTOR=1.0000E+00